


## INSTALLATION & OPERATION MANUAL S270S, S270P, S270J SERIES ENGINES



Applicable to S270S, S270P, S270J models

5th Edition



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

### TABLE OF CONTENTS

|                                                         |    |
|---------------------------------------------------------|----|
| ABOUT THIS MANUAL .....                                 | 3  |
| SAFETY PRECAUTIONS .....                                | 4  |
| APPROXIMATE STANDARD CONVERSIONS .....                  | 5  |
| CHAPTER 1 ENGINE OVERVIEW .....                         | 6  |
| 1. ENGINE COMPONENTS .....                              | 6  |
| 2. ENGINE HANGER .....                                  | 7  |
| 3. ENGINE IDENTIFICATION .....                          | 8  |
| 4. SCHEMATIC DIAGRAM OF COMMON RAIL DIESEL ENGINE ..... | 9  |
| 5. TECHNICAL DATA .....                                 | 10 |
| 6. PERFORMANCE CURVES .....                             | 11 |
| 7. BELT INSTALLATION & ENGINE DIMENSIONS.....           | 13 |
| CHAPTER 2 ENGINE MOUNT SYSTEM .....                     | 16 |
| 1. PREPARING THE ENGINE INSTALLATION .....              | 16 |
| 2. BELLHOUSING FIXING.....                              | 18 |
| 3. ASSEMBLING ENGINE MOUNTS .....                       | 18 |
| CHAPTER 3 COOLING & EXHAUST SYSTEM .....                | 19 |
| 1. SCHEMATIC DIAGRAM OF ENGINE COOLING CIRCUIT .....    | 19 |
| 2. SEAWATER FLOW.....                                   | 20 |
| 2.1 WATER PICKUP .....                                  | 20 |
| 2.2 SEAWATER STRAINER .....                             | 20 |
| 2.3 SEAWATER PUMP .....                                 | 21 |
| 3. ENGINE COOLANT FLOW.....                             | 23 |
| 3.1 ENGINE COOLANT .....                                | 23 |
| 3.2 REMOVING AIR BUBBLES.....                           | 25 |
| 3.3 CABIN HEATER CONNECTION .....                       | 25 |
| 4. EXHAUST SYSTEM .....                                 | 26 |
| CHAPTER 4 FUEL SYSTEM .....                             | 27 |
| 1. FUEL FLOW.....                                       | 28 |
| 2. LOW PRESSURE FUEL LINE .....                         | 29 |
| 3. ACCELERATION SENSOR AND CONTROL LEVER .....          | 29 |
| 4. RECOMMENDED FUEL QUALITY .....                       | 30 |
| 5. DRAINING WATER FROM FUEL FILTER .....                | 30 |
| CHAPTER 5 AIR INTAKE SYSTEM .....                       | 31 |
| 1. ENGINE AIR CONSUMPTION.....                          | 31 |
| 2. ENGINE ROOM VENTILATION.....                         | 31 |
| 3. AIR FILTER MAINTENANCE .....                         | 32 |
| CHAPTER 6 LUBRICATION SYSTEM .....                      | 33 |
| 1. ENGINE OIL FLOW.....                                 | 33 |
| 2. ENGINE OIL LEVEL CHECKS .....                        | 34 |
| 3. RECOMMENDED OIL QUALITY .....                        | 34 |
| 4. ENGINE OIL EXTRACTION PUMP .....                     | 35 |
| 5. OIL FILTER REPLACEMENT .....                         | 35 |

TABLE OF CONTENTS

|            |                                                      |    |
|------------|------------------------------------------------------|----|
| CHAPTER 7  | ELECTRICAL SYSTEM .....                              | 36 |
| 1.         | BATTERY CABLE CONNECTIONS .....                      | 36 |
| 2.         | BATTERY CHECKS .....                                 | 37 |
| 3.         | FUSE AND RELAY .....                                 | 38 |
| CHAPTER 8  | INSTRUMENT SYSTEM .....                              | 40 |
| 1.         | INSTRUMENT CONNECTIONS .....                         | 40 |
| 2.         | CUT-OUT FOR GAUGE .....                              | 43 |
| 3.         | CUT-OUT FOR EOI SYSTEM .....                         | 43 |
| 4.         | SEASLINK PRODUCT COMPONENTS.....                     | 44 |
| 5.         | INSTALLATION OF SEASALINK DONGLE.....                | 45 |
| CHAPTER 9  | EOI SYSTEM .....                                     | 46 |
| 1.         | OVERVIEW OF EOI SYSTEM .....                         | 46 |
| 1.1        | INFORMATION LCD .....                                | 46 |
| 1.2        | SWITCHES .....                                       | 47 |
| 1.3        | ALARM LAMPS .....                                    | 47 |
| 2.         | EOI CONNECTIONS .....                                | 48 |
| 3.         | EOI PIN ASSIGNMENT .....                             | 49 |
| 4.         | NEUTRAL SWITCH AND DUAL EOI CONNECTION .....         | 51 |
| 5.         | TRIM WIRING CONNECTION DIAGRAM .....                 | 52 |
| 6.         | G-SCAN.....                                          | 54 |
| 7.         | ALARM AND DTC(DIAGNOSIS TROUBLE CODE) .....          | 55 |
| 7.1        | ALARM AND DTC(DIAGNOSIS TROUBLE CODE) .....          | 55 |
| 7.2        | DTC(DIAGNOSIS TROUBLE CODE) LIST.....                | 58 |
| CHAPTER 10 | ANTI CORROSION SYSTEM .....                          | 63 |
| CHAPTER 11 | ENGINE OPERATION .....                               | 64 |
| 1.         | ENGINE ON/OFF .....                                  | 64 |
| 2.         | ENGINE BREAK-IN .....                                | 65 |
| 3.         | EMERGENCY STOP .....                                 | 66 |
| CHAPTER 12 | ENGINE STORAGE .....                                 | 67 |
|            | WINTER STORAGE.....                                  | 68 |
|            | LONG TERM STORAGE.....                               | 69 |
| CHAPTER 13 | MAINTENANCE .....                                    | 70 |
| 1.         | THE INITIAL RUNNING CHECK.....                       | 70 |
| 2.         | MAINTENANCE SCHEDULE .....                           | 71 |
| 3.         | STERNDRIVE & TRANSMISSION MAINTENANCE SCHEDULE ..... | 72 |
| 4.         | MAINTENANCE LOG.....                                 | 73 |
| CHAPTER 14 | TROUBLESHOOTING GUIDE .....                          | 74 |
| CHAPTER 15 | WARRANTY .....                                       | 76 |
|            | WARRANTY REGISTRATION CARD .....                     | 81 |

### ABOUT THIS MANUAL

This engine installation and operation manual is provided as guidance for the installation of a Hyundai SeasAll engine in a boat, and to describe engine operation. Its purpose is to provide technical information to aid in performing an effective engine installation so as to achieve both maximum performance and service life. For information on installation, operation and maintenance of the ZF Marine Transmissions and MerCruiser Bravo Sterndrive Models, please see the separate booklets included in the original packaging of your Hyundai SeasAll purchase.

Hyundai SeasAll is committed to making clear and accurate information available for those who maintain, own and repair the S270 Series engines. Hyundai SeasAll values your input regarding revisions and additional information for our manuals.

- The manufacturer is not liable for any damages or losses caused by faulty installation, wrong handling of the equipment and/or deficient maintenance.
- The operator is responsible for the correct and safe operation of the engine and safety of its occupants and general public.
- It is strongly recommended that each operator read and understand this manual before installing and operating the engine.
- This manual as well as safety labels posted on the engine use the following safety alerts to draw your attention to special safety instructions that should be followed.



### WARNING

**DEVIATION FROM INSTALLATION INSTRUCTIONS AND OPERATION GUIDELINES MAY LEAD TO PERSONAL INJURY OR DEATH TO OPERATORS AND NEARBY PERSONNEL.**



### CAUTION

**DEVIATION FROM INSTALLATION INSTRUCTIONS AND OPERATION GUIDELINES MAY LEAD TO IMPROPER OPERATION, DAMAGE OR DESTRUCTION OF THE ENGINE.**

## **SAFETY PRECAUTIONS**

- Read and understand this operator's manual as well as other information supplied by Hyundai SeasAll for safe use of these products. Be sure to check your engine regularly.
- Do not use the engine for a purpose other than what is intended by Hyundai SeasAll. Do not modify the performance of the supplied engine without the express permission of Hyundai SeasAll. This can be dangerous, can shorten the life of your engine and can invalidate your warranty.
- Original and genuine parts supplied from Hyundai SeasAll must be used for inspections and maintenance. Hyundai SeasAll does not guarantee any damage caused by the use of imitation parts.
- Engine inspection and maintenance should be carried out by properly trained and factory approved service engineers.
- The engine should be inspected if the electronic engine control unit shuts down the engine.

## **HOT SURFACES AND FLUIDS**

- There is always a risk of burns when working with a hot engine. Be aware of hot parts like the turbocharger system, the exhaust system, hot coolant hoses, etc. Wait until the engine is fully cool to do inspection and maintenance.

## **REFUELING**

- Refuel only after the engine completely stops.
- Use only the recommended fuel. The wrong grade of fuel can cause operating problems, can cause the engine to stop and can cause engine damage.
- Pay special attention to safe practices when refueling.

## **PAINT DAMAGE**

- Damage of the engine or parts paint during maintenance and inspection can cause corrosion. Any damage must be repainted after inspection and maintenance. Contact your Hyundai SeasAll dealer for touch-up paint.

## **WELDING ON ENGINE**

- Welding directly on the engine block can cause damage to the engine control systems. The ECU and related electronic devices must be disconnected and removed if unavoidable welding is needed.



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines


HYUNDAI SEASALL

| APPROXIMATE STANDARD CONVERSIONS |                   |             |                      |                    |                      |             |                   |
|----------------------------------|-------------------|-------------|----------------------|--------------------|----------------------|-------------|-------------------|
|                                  | SYMBOL            | MULTIPLY BY | SYMBOL               |                    | SYMBOL               | MULTIPLY BY | SYMBOL            |
| LENGTH                           | mm                | 0.039       | inch                 | LENGTH             | inch                 | 25.4        | mm                |
|                                  | cm                | 0.4         | inch                 |                    | inch                 | 2.54        | cm                |
|                                  | m                 | 3.28        | ft                   |                    | ft                   | 0.3048      | m                 |
| AREA                             | mm <sup>2</sup>   | 0.0016      | in <sup>2</sup>      | AREA               | in <sup>2</sup>      | 645.2       | mm <sup>2</sup>   |
|                                  | m <sup>2</sup>    | 10.764      | ft <sup>2</sup>      |                    | ft <sup>2</sup>      | 0.093       | m <sup>2</sup>    |
| VOLUME                           | cm <sup>3</sup>   | 0.061       | in <sup>3</sup>      | VOLUME             | in <sup>3</sup>      | 16.388      | cm <sup>3</sup>   |
|                                  | mL                | 0.06        | in <sup>3</sup>      |                    | in <sup>3</sup>      | 16          | mL                |
|                                  | Ldm <sup>3</sup>  | 61.023      | in <sup>3</sup>      |                    | in <sup>3</sup>      | 0.016       | Ldm <sup>3</sup>  |
|                                  | Ldm <sup>3</sup>  | 0.22        | imp.gallon           |                    | imp.gallon           | 4.545       | Ldm <sup>3</sup>  |
|                                  | Ldm <sup>3</sup>  | 0.264       | U.S.gallon           |                    | U.S.gallon           | 3.785       | Ldm <sup>3</sup>  |
|                                  | m <sup>3</sup>    | 0.76        | yd <sup>3</sup>      |                    | yd <sup>3</sup>      | 1.3         | m <sup>3</sup>    |
|                                  | m <sup>3</sup>    | 35.315      | ft <sup>3</sup>      |                    | ft <sup>3</sup>      | 0.028       | m <sup>3</sup>    |
| FORCE                            | kgf               | 2.204       | lbf                  | FORCE              | lbf                  | 0.453       | kgf               |
|                                  | N                 | 0.224       | lbf                  |                    | lbf                  | 4.448       | N                 |
| TEMP.                            | °F=9/5x°C+32      |             |                      | TEMP.              | °C=5/9x(°F-32)       |             |                   |
| PRESSURE                         | Bar               | 14.5        | psi                  | PRESSURE           | psi                  | 0.068       | Bar               |
|                                  | MPa               | 145         | psi                  |                    | psi                  | 0.0068      | MPa               |
|                                  | Pa                | 0.102       | mmWc                 |                    | mmWc                 | 9.807       | Pa                |
|                                  | Pa                | 0.004       | inWc                 |                    | inWc                 | 249.098     | Pa                |
|                                  | KPa               | 4           | inWc                 |                    | inWc                 | 0.249       | KPa               |
|                                  | mWg               | 39.37       | inWc                 |                    | inWc                 | 0.025       | mWg               |
| TORQUE                           | Nm                | 0.738       | lbf ft               | TORQUE             | lbf ft               | 1.356       | Nm                |
| WEIGHT                           | kg                | 2.205       | lb                   | WEIGHT             | lb                   | 0.454       | kg                |
|                                  | kg                | 35.273      | oz                   |                    | oz                   | 0.028       | kg                |
| WORK                             | kJ/kWh            | 0.43        | BTU/lb               | WORK               | BTU/lb               | 2.326       | kJ/kWh            |
|                                  | MJ/kg             | 430         | BTU/lb               |                    | BTU/lb               | 0.0023      | MJ/kg             |
|                                  | kJ/kg             | 0.24        | Kcal/kg              |                    | Kcal/kg              | 4.184       | kJ/kg             |
| ENERGY                           | kJ/kg             | 0.697       | BTU/hph              | ENERGY             | BTU/hph              | 1.435       | kJ/kg             |
| FUEL CONSUMP.                    | g/kWh             | 0.736       | g/hph                | FUEL CONSUMP.      | g/hph                | 1.36        | g/kWh             |
|                                  | g/kWh             | 0.0016      | lb/hph               |                    | lb/hph               | 616.78      | g/kWh             |
| FLOW RATE (GAS)                  | m <sup>3</sup> /h | 0.588       | ft <sup>3</sup> /min | FLOW RATE (GAS)    | ft <sup>3</sup> /min | 1.699       | m <sup>3</sup> /h |
| FLOW RATE (LIQUID)               | m <sup>3</sup> /h | 4.403       | US gal/min           | FLOW RATE (LIQUID) | US gal/min           | 0.2271      | m <sup>3</sup> /h |
| SPEED                            | m/s               | 3.281       | ft/s                 | SPEED              | ft/s                 | 0.3048      | m/s               |
|                                  | km/h              | 0.539       | knots                |                    | knots                | 1.852       | km/h              |
|                                  | mph               | 0.869       | knots                |                    | knots                | 1.1508      | mph               |
|                                  | km/h              | 0.62        | mph                  |                    | mph                  | 1.61        | km/h              |


### CHAPTER 1

### ENGINE OVERVIEW

#### 1. ENGINE COMPONENTS




- |                           |                              |
|---------------------------|------------------------------|
| 1. ECU Box                | 7. Engine Oil Gauge          |
| 2. Coolant Expansion Tank | 8. Acceleration Lever Sensor |
| 3. Engine Oil Cap         | 9. Seawater Pump             |
| 4. Engine Oil Filter      | 10. Intercooler              |
| 5. E-VGT & Cooler         | 11. Heat Exchanger           |
| 6. Air Filter             | 12. Alternator               |



- |                                     |                                                         |
|-------------------------------------|---------------------------------------------------------|
| 1. Turbo Heat Protector             | 7. Power Steering Oil Reservoir Tank (Sterndrive Model) |
| 2. Exhaust Elbow                    | 8. Shift Plate (Sterndrive Model)                       |
| 3. Bell Housing (Sterndrive Model)  | 9. Main Fuel Filter with Water Detection Sensor         |
| 4. Drive Coupler (Sterndrive Model) | 10. T/M Oil Cooler or P/STRG Oil Cooler                 |
| 5. Engine Oil Drain Pump Button     | 11. Cabin Heater Connector                              |
| 6. Engine Emergency Stop Button     | 12. Boost Pressure Sensor                               |

### 2. ENGINE HANGER

- 1) To lift the engine, first remove the engine cover. You will find three engine eyes (see figure).
- 2) To avoid damage to the engine or operator, take care that engine lift chains or belts do not hit or touch surrounding parts during engine lifting.




### 3. ENGINE IDENTIFICATION

Engine identification is affixed to the engine block and the ECU box (see figure).


▪ SERIAL NUMBER ON THE ENGINE BLOCK



▪ NAME PLATE ON THE ECU BOX



### 4. SCHEMATIC DIAGRAM OF COMMON RAIL DIESEL ENGINE




### 5. TECHNICAL DATA

| Engine type                                     | S270S                                         | S270P      | S270J    |
|-------------------------------------------------|-----------------------------------------------|------------|----------|
|                                                 | 4-stroke, 24-valve                            |            |          |
|                                                 | After-cooled, direct-injection, water cooling |            |          |
| Output PS(kW)                                   | 270PS (199)                                   |            |          |
| rpm at full load                                | 3800                                          |            |          |
| Cylinders                                       | V-6                                           |            |          |
| Ignition sequence                               | 1-2-3-4-5-6                                   |            |          |
| Displacement [cm³]                              | 2959                                          |            |          |
| Bore [mm]                                       | 84                                            |            |          |
| Stroke [mm]                                     | 89                                            |            |          |
| Compression ratio                               | 17.3±0.5 : 1                                  |            |          |
| Max. torque [kgm]<br>@ speed [rpm]              | 57.6                                          | 51         |          |
|                                                 | 2500                                          | 3800       |          |
| Injection system                                | Common rail direct injection (Piezo injector) |            |          |
| Diesel fuel                                     | at least CN 51 as per DIN EN 590              |            |          |
| Intake air pressure (abs. bar)<br>@ speed [rpm] | 2.78                                          | 2.78       | 2.78     |
|                                                 | 3800                                          | 3800       | 3800     |
| Coolant quantity (liter)                        | 13.15                                         |            |          |
| Coolant cap opening pressure (bar)              | 1.1                                           |            |          |
| Engine oil (liter)                              | 7.7                                           |            |          |
| Engine oil pressure (bar)                       | 2~3 at 1750rpm, 100 °C (oil temp.)            |            |          |
| Exhaust gas pressure (kPa)                      | Max. 50                                       |            |          |
| Alternator [A]                                  | 150                                           |            |          |
| Engine diagnosis                                | Yes                                           |            |          |
| Weight(kg)                                      | 327                                           |            |          |
| Battery capacity (AH)                           | 12V, 200AH recommended                        |            |          |
| Thermostat opening temp. (°C)                   | 71 (starting to open), 80 (fully open)        |            |          |
| Idle rpm warmed up (rev/min)                    | 680                                           |            |          |
| Permissible eng. oil temp (°C)                  | 137                                           |            |          |
| Permissible eng. coolant temp (°C)              | 105                                           |            |          |
| Fuel Consumption (Rated) (l/hr) @               | 53.8 @ 3800 rpm                               |            |          |
| Propulsion system                               | Sterndrive                                    | Shaftdrive | Waterjet |


6. PERFORMANCE CURVE

▪ S270S & S270P MODEL



\*F.C : Fuel Consumption

▪ S270J MODEL




\*F.C : Fuel Consumption


### 7. BELT INSTALLATION & ENGINE DIMENSIONS

#### ▪ V-RIBBED BELT INSTALLATION


| MODEL : S2-ENG SERIES |                   |
|-----------------------|-------------------|
| AN                    | ALTERNATOR        |
| DP                    | DRIVE PULLEY      |
| IP                    | IDLER PULLEY      |
| PS                    | POWER STEERING    |
| TP                    | TENSIONER PULLEY  |
| WP                    | WATER PUMP PULLEY |




#### ▪ MerCruiser Bravo One X Diesel




#### ▪ MerCruiser Bravo Two X Diesel




▪ MerCruiser Bravo Three X Diesel




▪ ZF 63 A



▪ ZF 63 C




Front view




Side view

▪ Waterjet adapter without ZF 63 C



Front view




Side view

### CHAPTER 2

### ENGINE MOUNT SYSTEM

#### 1. PREPARING THE ENGINE INSTALATION

- It is essential that the engine bed is perfectly flat before using the engine mount tool.
- Make sure that the rubber engine mounts are installed so that no pre-load or side forces occur when the engine has been installed and aligned with the stern drive




#### 1.1 CHECK THE MOUNT HOLE

Mark 'R': Mount hole for R200S


Mark 'S': Mount hole for S270S & S250S

Mark 'U': Mount hole for U125S

Mark 'D': Mount hole for D170S & D150S



<Engine mount tool>



<Check the position of the engine mounts >

- Engine installation must be done by a qualified technician. Hyundai SeasAll engines must be aligned using the genuine Hyundai SeasAll alignment tool. Otherwise the drive coupler will be damaged.




< Hyundai-SeasAll alignment tool(5 Step) >



< MerCruiser alignment tool(4 Step) >

### 1.2 CHECK THE MOUNT BED

- To avoid the interference with engine parts, below dimension is should be considered.



\* Left side view is needed same dimension




# INSTALLATION & OPERATION MANUAL

## S270 Series Engines


### 2. BELLHOUSING FIXING

- Assemble exhaust pipe after tightening the mounting bolts between bell housing and transom plate. Use the following parts:


- ① Mounting Bolt
- ② Washer
- ③ Spacer
- ④ Fiber Washer
- ⑤ Nut



### 3. ASSEMBLING ENGINE MOUNTS




**WARNING**  
DON'T USE THE SPRING WASHER.  
IF YOU USE SPRING WASHER, THE PROBLEM OF  
ENGINE ALIGNMENT CAN BE OCCURRED.



- 1) To prevent twisting the engine mount during engine alignment, use a spanner on the lower nut (①) to keep the bolt from turning while adjusting the engine height by turning the middle nut (②). Adjust the engine height until the Hyundai SeasAll alignment tool can be properly inserted.


- 2) After alignment, place washer (③) on top of engine support bracket and tighten lock nut (④) while keeping the middle nut (③) from turning with a spanner.





### CHAPTER 3

### COOLING SYSTEM & EXHAUST SYSTEM

#### 1. SCHEMATIC DIAGRAM OF ENGINE COOLING CIRCUIT



### 2. SEAWATER FLOW – OPEN COOLING CIRCUIT



EVGT cooler


※ **Cleaning the inside of the cooler every 250 hours or every year.**

#### 2.1 WATER PICKUP

- 1) Water pickup should be installed in an area where it won't pick up air bubbles and will access clean water during all phases of the engine operation.
- 2) After start up, you must check for air bubbles by inspecting the waterline. Bubbles will appear if there is a leakage from the waterline. If bubbles appear, leakage area must be detected and completely sealed prior to engine operation.
- 3) For sterndrive models, please see the section "Installing Sterndrive Seawater Pickup" of the Bravo Sterndrive Installation Manual included in the original packaging.
- 4) For further safety, you must install an additional transom or bottom mounted clamshell-type water pickup. Water flow from the Bravo sterndrive leg only is not adequate to provide proper engine cooling.

#### 2.2 WATER STRAINER

- 1) Strainer should be located in an area where it will be easily accessible for periodic seawater flow inspection and cleaning.
- 2) The size of strainer must be of sufficient capacity to pass the seawater (a minimum flow rate over 200 liters per minute).
- 3) Strainer must be installed after water inlet valve in order to allow user to shut off seawater when cleaning strainer filter.





### CAUTION

**IF THE SEAWATER STRAINER IS NOT PROPERLY ASSEMBLED, AIR CAN BE SUCKED INTO THE COOLING CIRCUIT, DISTURBING THE VACUUM PROCESS. THIS CAN CAUSE THE ENGINE TO OVERHEAT.**

### 4) To clean strainer filter,

- Stop the engine and close the water valve
- Remove the filter cap
- Remove the filter element, flush it thoroughly with clean water or compressed air
- Insert the cleaned filter element and screw on the filter cap
- Check the cap and the gasket for correct seating and sealing
- Open the water valve
- Start the engine and check if there is water leakage

## 2.3 SEAWATER PUMP



- The internal diameter of the hose connected to seawater pump inlet should be 45~46mm.
- The cross section of the hose may shrink due to inlet pressure drop. Therefore, the hose from water pickup in the boat's hull to the seawater pump inlet should be as short as possible and must be made of steel wire reinforced material.
- The seawater pump impeller must be checked periodically and replaced if necessary.

## CHECKING SEA WATER PUMP & IMPELLER

- Stop the engine and close the water valve
- Remove the impeller housing cover
- Remove the impeller from inside the seawater pump
- Check the condition of impeller and bushing
- Apply soapy water to impeller when assembling, and reassemble towards rotation direction
- Replace of the O-ring on the impeller housing cover
- Open the water valve
- Start the engine and check if there is water leakage



### CAUTION

IF THE SEAWATER STRAINER IS NOT PROPERLY ASSEMBLED, AIR CAN BE SUCKED INTO THE COOLING CIRCUIT, DISTURBING THE VACUUM PROCESS. THIS CAN CAUSE THE ENGINE TO OVERHEAT.



### CAUTION

DO NOT RUN THE ENGINE WITHOUT SEAWATER. THE SEAWATER PUMP IMPELLER WILL BE DAMAGED. BEFORE STARTING THE ENGINE, BE SURE TO SUPPLY SEAWATER TO THE PASSAGES.



### CAUTION

IMPELLER DAMAGE MAY OCCUR IF APPROPRIATE TOOLS ARE NOT USED WHEN REMOVING THE IMPELLER. MAKE SURE TO CHECK O-RING CONDITION AFTER SEAWATER PUMP REASSEMBLY.




### CAUTION

DO NOT INSTALL ADDITIONAL DEVICES WHICH COULD OBSTRUCT THE FLOW OF SEAWATER. THIS CAN CAUSE THE ENGINE TO OVERHEAT.


### 3. ENGINE COOLANT FLOW – CLOSED COOLING CIRCUIT

#### ▪ THERMOSTAT CLOSED CONDITION



- ① Coolant engine outlet  
↓  
② Exhaust manifolds (both)  
↓  
Thermostat closed (opening temp 71 °C)  
↓  
③ Coolant engine inlet


#### ▪ THERMOSTAT OPENED CONDITION



- ① Coolant engine outlet ———→ ④ Expansion tank  
↓  
② Heat exchanger      ⑤ Exhaust manifolds (both)  
↓  
Thermostat opened (opening temp 71 °C)  
↓  
③ Coolant engine inlet ←————

### 3.1 ENGINE COOLANT


- 1) The high-pressure cooling system has a reservoir filled with year-round antifreeze coolant. The reservoir is filled at the factory.
- 2) The coolant level should be between MAX and MIN marks on the side of the coolant reservoir when the engine is cool.



- 3) If the coolant level is low, add enough specified coolant to provide protection against freezing and corrosion. Bring the level to MAX, but do not overfill.
- 4) If frequent additions are required, see an authorized dealer for a cooling system inspection.
- 5) Use only soft (demineralized) water in the coolant mixture.
- 6) The engine has aluminum engine parts and must be protected by an ethylene-glycol based coolant to prevent corrosion and freezing.
- 7) DO NOT USE alcohol or methanol coolant or mix them with the specified coolant.
- 8) DO NOT USE a solution that contains more than 60% antifreeze or less than 35% antifreeze, which would reduce the effectiveness of the solution.
- 9) For mixture percentages, refer to the following table:

| Ambient Temperature | Mixture Percentage(volume) |       |
|---------------------|----------------------------|-------|
|                     | Antifreeze                 | Water |
| -15℃°(5°F)          | 35                         | 65    |
| -25℃°(13°F)         | 40                         | 60    |
| -35℃°(31°F)         | 50                         | 50    |
| -45℃°(49°F)         | 60                         | 40    |

- 10) In order to drain engine coolant, please use a screwdriver to loosen the drain plug  
①.The drain plug is located under the heat exchanger unit.



ENGINE COOLANT DRAIN PLUG


### 3.2 REMOVING AIR BUBBLES IN COOLANT LINE

- 1) Start the engine and warm it up at a low rpm (up to thermostat opening)
- 2) Next, stop the engine and allow the engine to cool enough, and then open the cap of the expansion tank carefully.  
\*NOTE: Never open the cap when the engine is hot. Doing so may cause scalding.
- 3) Refill with coolant if needed.
- 4) Recap the expansion tank.
- 5) Please check the level of expansion tank regularly while driving.

### 3.3 CABIN HEATER CONNECTION

- 1) In order to use cabin heater, an extra coolant circulation pump is needed.
- 2) After connecting cabin heater lines, engine coolant must be refilled and checked.
- 3) Please check coolant flow direction, as shown in the figure.
- 4) If in doubt, please contact your nearest Hyundai SeasAll dealer.

\*After installing a cabin heater and refilling the system, the coolant in the coolant expansion tank may initially overflow.



\* Outer diameter of pipe is  $\varnothing 17.3$  mm





### WARNING

NEVER OPEN THE EXPANSION TANK CAP WHEN THE ENGINE IS OPERATING OR HOT. IT MAY CAUSE ENGINE DAMAGE AND COULD RESULT IN SERIOUS PERSONAL INJURY.

### 4. EXHAUST SYSTEM

- 1) Your Hyundai SeasAll engine's exhaust system consists of a coolant-cooled exhaust manifold and a seawater-cooled exhaust elbow (water injected wet exhaust system).
- 2) The vessel's exhaust pipe line should not be made too long or to bend. The maximum back pressure of the exhaust gas should be under 50kPa.
- 3) Make sure that the shortest height between bottom of the exhaust elbow and the center of the crank axis is 36cm.
- 4) If the distance between the bottom of the exhaust elbow and the waterline is less than 15cm, or if the waterline is above the water injection point, there is a risk of flowing back (siphoning by engine stopping and outside seawater entering through the transom exhaust hole).
- 5) In order to avoid this risk, a vacuum breaker and exhaust riser are needed. If in doubt about exhaust system installation, please contact your nearest Hyundai SeasAll dealer.



**EXHAUST RISER**




### CAUTION

IF IN DOUBT ABOUT EXHAUST SYSTEM INSTALLATION, PLEASE CONTACT YOUR NEAREST HYUNDAI SEASALL DEALER.



### CHAPTER 4

### FUEL SYSTEM



The fuel supply system of this engine is diesel common rail direction injection. In order to optimize engine combustion, its maximum injection pressure is up to 1800 bar. Multi-injection is possible thanks to the quick response of the piezo type injector.



### 1. FUEL FLOW




### 2. LOW PRESSURE FUEL LINE



- ① Return line to fuel tank ( engine out )
- ② Return line from injector to main fuel filter ( engine out )
- ③ Feeding line from main fuel filter
- ④ Feeding line from fuel tank to electric feed pump (low pressure pump)
- ※ The internal diameter of all fuel lines must be at least 8 mm.

### 3. ACCELERATION SENSOR AND CONTROL LEVER

When installing control lever cable to acceleration sensor, be sure that the acceleration sensor lever is fully released to the idle position and fully pulled to the full-load position. The swing distance of lever between idle and full-load position is 60mm.





#### The procedures for control lever installation

##### 1) Idle position setting

Make sure that the position value (%) should indicates 0% at neutral condition.

##### 2) Full load position setting

Make sure that the position value (%) should indicates full load range (90~99.2%) at fully forward lever condition. If not adjust sleeve of control cable



## CAUTION

**YOU SHOULD PERFORM ABOVE PROCEDURES AFTER CONTROL LEVER INSTALLATION WHEN ENGINE IS NOT RUNNING BUT IGNITION KEY IS ON.**

### 4. RECOMMENDED FUEL QUALITY


The following fuels should be used for engine operation:

- Standard summer / winter diesel fuel according to DIN EN 590 (classes A-F)
- Diesel fuel according to DIN EN 590 (classes 0-4) in arctic climates
- Summer diesel fuel according to California and U.S. federal regulations
- Winter diesel fuel if lubricity is comparable to diesel fuel according to DIN EN 590
- Mixture of diesel fuel with 5 Vol.% RME according to DIN 51606
- Later admixing or additional use of additives, gasoline or special fuels is not permitted

### 5. DRAINING WATER FROM FUEL FILTER

- 1) The fuel filter for a diesel engine plays the important role of separating water from fuel and accumulating the water in its base. If water accumulates in the fuel filter, a warning light comes on when the ignition switch is in the ON position.
- 2) If the water in the fuel filter is over the limit, the Water Sensor Lamp on the EOI will light up. If this happens, you must stop the engine and drain the water in fuel filter yourself or ask the nearest workshop to do this.
- 3) Water and a little fuel will drain at the same time. Therefore, avoid flames in your workspace.
- 4) If your fuel is not well suited to your engine, more frequent drainage will be required.
- 5) To check and drain the water in fuel filter:

- Loosen the drain plug (part ①) and drain water. 100 ~ 200cc drainage is proper
- After water is drained, securely tighten the drain plug
- After starting the engine, check to make certain the fuel filter warning light is off



## CAUTION

HYUNDAI SEASALL'S GUARANTEES OR WARRANTIES ARE VOID IN CASES WHERE DAMAGE TO THE FUEL INJECTION COMPONENTS (HIGH PRESSURE PUMP, INJECTORS, ETC.) CAN BE ATTRIBUTED TO THE USE OF UNQUALIFIED FUELS.

IF THE WATER ACCUMULATED IN THE FUEL FILTER IS NOT DRAINED AT PROPER TIMES, DAMAGE TO MAJOR ENGINE PARTS WILL OCCUR. WHEN REPLACING THE FUEL FILTER CARTRIDGE, USE GENUINE PARTS ONLY.

### CHAPTER 5

### AIR INTAKE SYSTEM

#### 1. ENGINE AIR CONSUMPTION

- The engine needs to have a proper volume of intake air for combustion. This requires a minimum internal area of air supply ducting the area can be calculated by using the following formula:

A = cross section of area in cm<sup>2</sup>

A = **1.9 X Engine power (KW)**

→ A = 1.9 X 199 (KW) = 378.1cm<sup>2</sup> = **Ø 21.95cm**

Area =  $\pi r^2$ . (378.1 /  $\pi$  (3.14)) = 120.

Square Root of 120 = 10.95 = radius. 2 x radius = diameter (21.95)

Minimum intake area is **Ø21.95cm**. When use longer ducts or more bends are used the area is corrected by multiplying by coefficient from the table above. We recommend to position the air inlet around 25~35cm from the air filter. The air inlet must never be installed in the transom as water and/or exhaust gases could be ingested.

| Number of pipe bends (90°) | Length of pipe (Meters) |      |      |      |      |
|----------------------------|-------------------------|------|------|------|------|
|                            | 1                       | 2    | 3    | 4    | 5    |
| 1                          | 1                       | 1.04 | 1.09 | 1.13 | 1.20 |
| 2                          | 1.39                    | 1.41 | 1.43 | 1.45 | 1.49 |
| 3                          | -                       | 1.70 | 1.72 | 1.74 | 1.78 |

Example) Length of pipe : 3M , number of pipe bands : 2

→ Ø21.95cm X 1.43 = Ø31.38cm

※ **Minimum Bending Radius = 2 X O.D of pipe (90° case)**

#### 2. ENGINE ROOM VENTILATION

- Engine room needs proper ventilation for optimum engine operation. This requires a minimum internal area of air ventilation. The area can be calculated by using the formula:

A = **1.65 X Engine power (KW)**

→ A = 1.65 X 199 (KW) = 328.3cm<sup>2</sup> = **Ø20.45cm**

- Minimum ventilation area is **Ø20.45cm**, when using longer ducts or more bends are used the area is corrected by multiplying by coefficient from the table above. **The air inlet and outlet vents should be the same size.** The distance between air inlets and air outlets should be as far as possible from each other. If the distance is too short, air will not circulate properly which will result in bad ventilation. **A blower should be installed** in the exhaust air duct to ventilate and cool the engine room more effectively.

**Extraction fan capacity (Air Flow m<sup>3</sup>/min) = 0.07 X Engine power (KW)**


→ **Extraction fan capacity = 0.07 X 199 (KW) = 13.9m<sup>3</sup>/min**

※ **General pressure drop of Engine room = 0.1~0.5kPa**

Example) Length of pipe : 3M , number of pipe bands : 2

→ Ø20.45cm X 1.43 = **Ø29.24cm**

### 3. AIR FILTER MAINTENANCE



- The original Hyundai SeasAll air cleaner may be cleaned and reused.
- If the air filter is very dirty, it can increase airflow resistance and reduce flow of air to the engine. This can result in reduced power and fuel efficiency.
- Cleaning the air filter should be carry out periodically according to the procedure below.
- Do not clean the filter element with gasoline or other solvent cleaners.
- Remove the air filter from engine.
- Put the air filter on a flat surface and shake dust out.
- Liberally spray K&N Air filter Cleaner onto both sides the of filter and allow to soak for 10 minutes to loosen the dirt.
- Wash out the dust with low pressure running water from the inside toward the outside.
- Dry the wet air filter in the shade for 2~3 hour. You can reduce drying time by blowing with a hair dryer on COLD or by blowing with low pressure compressed air.
- (CAUTION) Do not use high pressure air, high pressure water or hot air to clean and/or dry the air filter. These can damage the performance of the air filter.
- Apply air cleaner oil over the outside of the filter. If too much oil is applied, it will reduce performance.
- Reassemble air filter to engine.




### CAUTION

WHEN REMOVING THE AIR FILTER, BE CAREFUL THAT DUST OR DIRT DOES NOT ENTER THE AIR INTAKE, OR DAMAGE MAY RESULT. DO NOT RUN WITHOUT AIR CLEANER. THIS COULD RESULT IN EXCESSIVE ENGINE WEAR. USE OF NON-GENUINE PARTS COULD DAMAGE THE TURBO CHARGER OR ENGINE.

### CHAPTER 6


### LUBRICATION SYSTEM

#### 1. ENGINE OIL FLOW



2. ENGINE OIL LEVEL CHECKS

- The engine oil level must be checked at regular intervals.
- Be sure the boat is level.
- Start the engine and allow it to reach normal operating temperature.
- Turn the engine off and wait about 5 minutes, until the oil has returned to the oil pan.
- Pull the dipstick out, wipe it clean, and re-insert it fully.
- Pull the dipstick out again and check the level. The level should be between F and L. If it is near or at L, add enough oil to bring the level to F. Do not fill with engine oil above the F mark.




3. RECOMMENDED OIL QUALITY

For best performance and maximum protection during all types of operation, select only those lubricants which :

- 1) Satisfy the requirement of the API or ACEA classification.
- 2) Have proper SAE grade number for expected ambient temperature range.

| Description |      | Specifications | Limit                                                             |
|-------------|------|----------------|-------------------------------------------------------------------|
| Oil quality | ACEA | Above B4       | Service oil quality should conform to ACEA or API classification. |
|             | API  | Above CH - 4   |                                                                   |
|             | SAE  | 15W-40         | -15°C above                                                       |
|             |      | 10W-30         | -20°C ~ 40°C                                                      |
|             |      | 5W-30          | -25°C ~ 40°C                                                      |
|             |      | 0W-30          | 10°C below                                                        |


### 4. ENGINE OIL EXTRACTION PUMP



- 1) Allow the engine to warm up at least 5 minutes.
- 2) Remove the engine oil inlet cap and oil filter.
- 3) The oil drain hose is connected to the oil extraction pump ①, route the loose end of the hose into the container being used for the oil change ②.
- 4) Turn the ignition key ON (but do NOT start the engine) then press and hold button ③ on the left side of the ECU box with the ignition switched on until the engine oil is completely pumped out.

### 5. OIL FILTER REPLACEMENT

- 1) Remove the oil filter cap by using a 32mm wrench; loosen the oil filter cap slowly. Be careful not to drop engine oil while the oil filter paper is removed with its cap.
- 2) Remove the oil filter element (A) and its O-ring (B) from its cap.
- 3) Replace the filter element assembly and O-ring with the new ones that are supplied as a service kit. Do not reuse the removed O-ring.
- 4) Assemble the oil filter cap with the filter fixed. The tightening torque is 24.5Nm (2.5kgf·m, 18.1lb-ft).



### WARNING

**USED OIL MUST BE STORED IN A SAFE PLACE AWAY FROM CHILDREN AND SOURCES OF IGNITION. IF YOU HAVE A USED OIL DISPOSAL PROBLEM, PLEASE HAVE THE ENGINE OIL CHANGED BY YOUR NEAREST HYUNDAI SEASALL SERVICE DEALER.**



### CHAPTER 7

### ELECTRICAL SYSTEM

#### 1. BATTERY CABLE CONNECTIONS

- 1) The size of battery cable should be at least 40mm<sup>2</sup> and no longer than 4m.
- 2) If the cable is longer than 4m. the size should be at least 50mm<sup>2</sup>
- 3) Recommended battery capacity is over 200 amperes.
- 4) Connect the battery (+) cable from the battery to the starter motor with the cable from alternator (+) cable.
- 5) Connect the battery (-) cable and system ground connector to alternator housing or Engine block.

- \* In case of a “Two Pole System”, connect battery (-) cable to the alternator housing.
- 6) Battery cables connectors should be clean and tightly fastened.



### CAUTION

DO NOT TOUCH OR REMOVE ELECTRICAL PARTS WHEN STARTING OR DURING OPERATION.  
KEEP HAND, HAIR, AND CLOTHES AWAY FROM THE FLYWHEEL AND OTHER ROTATING PARTS WHILE THE ENGINE IS RUNNING.

2. BATTERY CHECKS

Battery inspection is very important in electronic control engines: You must check the battery condition regularly.

LOAD TEST

- 1) Perform the following steps to complete the load test procedure for maintenance-free batteries.
- 2) Connect the load tester clamps to the terminals and proceed with the test as follows:
  - a. If the battery has been charged, remove the surface charge by connecting a 300 ampere load for 15 seconds.
  - b. Connect the voltmeter and apply the specified load.
  - c. Read the voltage after the load has been applied for 15 seconds.
  - d. Disconnect the load.
  - e. Compare the voltage reading with the minimum and replace the battery if battery test voltage is below that shown in the voltage table. If the voltage is greater than shown in the table, the battery is good. If the voltage is less than shown in the table, replace the battery.

| Voltage | Temperature           |
|---------|-----------------------|
| 9.6     | 20°C (70°F) and above |
| 9.5     | 16°C (60°F)           |
| 9.4     | 10°C (50°F)           |
| 9.3     | 4°C (40°F)            |
| 9.1     | -1°C (30°F)           |
| 8.9     | -7°C (20°F)           |
| 8.7     | -12°C (10°F)          |
| 8.5     | -18°C (0°F)           |



**WARNING**

BATTERY MUST BE STORED AND WORKED ON IN A SAFE PLACE AWAY FROM CHILDREN AND SOURCES OF IGNITION. FLUID IN THE BATTERY IS A CORROSIVE ACID AND MUST BE HANDLED WITH CARE. IF SPILLED ON ANY PART OF BODY, FLUSH IMMEDIATELY WITH WATER.



**CAUTION**

DO NOT LOOSEN OR DETACH BATTERY TERMINALS WHILE ENGINE IS RUNNING. DOING SO WILL DAMAGE CHARGING SYSTEM AND OTHER ELECTRONIC DEVICES.

### 3. FUSE AND RELAY

#### 3.1 FUSE

An engine's electrical system is protected from electrical overload damage by fuses.


If a fuse has blown, the element inside the fuse will be melted. If the electrical system does not work, first check the fuses in ECU box. Always replace a blown fuse with one of the same rating.



If the replacement fuse blows, this indicates an electrical problem. Avoid using the system involved and immediately consult an authorized Hyundai SeasAll dealer.

#### Fuses in the ECU Box


- 1) System Power: 30Amp
- 2) Ignition Power: 5Amp
- 3) ECM(ECU) Power: 20Amp
- 4) Main Relay Power: 15Amp
- 5) Spare: 30Amp
- 6) Fuel Filter: 30Amp



**3.2 RELAYS**

**Relays in the ECU Box**


- 1) Main Relay: 30 Amp
- 2) Oil Extraction Pump Relay: 30 Amp
- 3) Fuel Pump Relay : 30 Amp
- 4) Fuel Heater Relay: 30 Amp
- 5) Start Solenoid Relay: 30 Amp
- 6) Glow Relay: 70 Amp



- Using an ohmmeter, check that there is continuity between each terminal.

| Terminal | Continuity |
|----------|------------|
| 30 - 87  | NO         |
| 85 - 86  | YES        |


- Check for continuity between terminals 30 and 87.
- Always replace a damaged relay with one of the same rating.





### CHAPTER 8 INSTRUMENT SYSTEM

#### 1. INSTRUMENT CONNECTIONS



① Engine to EOI wiring (5m/7m/10m/15m)

② EOI to RPM gauge (Ø 85) Wiring

③ EOI to coolant temp gauge (Ø 52) Wring

④ EOI to volt gauge(Ø 52) Wring

⑤ EOI to Ignition key switch(Ø 57) Wring

⑥ Dual EOI wiring (option for dual stage)

⑦ SeasLink Dongle (Connect to OBD Terminal in EOI) [00760-BS1G1]

[00112-7D195, 00112-5S197,  
00112-5S190, 00112-5S196]

[00113-5S104, 00113-5S1G4(Chrome)]

[00113-5S105, 00113-5S1G5(Chrome)]


[00113-5S106, 00113-5S1G6(Chrome)]

[00113-5S107]

[00112-5S199(5M), 00112-5S200(7M)]

※ For information about the installation and operation of the EOI (Engine Operating Indicator) system, please refer to Chapter 9.

### 1.1 STANDARD INSTRUMENTS




- ① RPM Gauge
- ② Coolant Temperature Gauge
- ③ Battery Voltmeter Gauge
- ④ Ignition Key switch

NOTE: Gauge panel (show above) is not standard but available as an option


### 1.2 COOLANT TEMPERATURE GAUGE

- This gauge will work when the key is in the 'ON' position.
- Avoid max. rpm and WOT (Wide Open Throttle) before a cold engine is fully warmed up as it can harm the engine.
- The gauge needle should be in proper range. If the outside temperature is high, the gauge needle may sit at a higher range. As long as the alarm doesn't sound, the engine is normal.
- If the gauge blinks and an EOI alarm sounds, check the coolant temperature and level. If the coolant is low, refill it.
- If the temperature of the engine coolant is higher than 105°C, the engine power will decrease. You should check the engine cooling system.



### 1.3 RPM GAUGE





- 1) When the key is at ignition ON position, this gauge will work.
- 2) This gauge indicates real-time engine rpm.
- 3) Avoid max. rpm and WOT (Wide Open Throttle) before a cold engine is fully warmed up, as it can harm the engine.




### 1.4 How to use RPM gauge and operation information indication (LCD)

- Pushing the Left or Right button will cycle through the information shown on the right. If a problem occurred, a warning lamp will turn on

<Warning Lamp>


|                                                                                     |                                         |
|-------------------------------------------------------------------------------------|-----------------------------------------|
|  | Engine Check Symbol                     |
|  | High Coolant Temperature Symbol (>110℃) |
|  | Low Battery Symbol                      |
|  | Glow Plug Operating Symbol              |

※ **Reset : Press left and right buttons at the same time for 3 seconds.**

|                                                                                                       |                                                                                 |
|-------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------|
| Throttle %<br><b>65</b>                                                                               | ● Throttle Lever Position : 65%                                                 |
| Cons l/h<br><b>12.5</b>                                                                               | ● Fuel Consumption : 12.5 l/h                                                   |
| Cool ℃<br><b>94</b>                                                                                   | ● Coolant Temperature : 94 ℃                                                    |
| Battery v<br><b>13.8</b>                                                                              | ● Battery Voltage : 13.8V                                                       |
| Dimmer Control<br> | ● LCD Display Brightness Control<br>Press left or right button for 3 seconds.   |
| Hour h<br><b>30</b><br><b>253</b>                                                                     | ● Running Time after reset : 30 Hr<br>● Total Accumulated Running Time : 253 Hr |

### 1.5 BATTERY VOLT METER GAUGE

- This gauge will work when the key is in the "ON" position.
- This gauge indicates real-time battery voltage.
- If battery voltage is not sufficient, the engine can not be started.
- For a working engine, 12 ~ 16V volts is normal. If the battery voltage is under 12V, you should check battery and alternator.
- At the moment of engine ignition, the voltmeter needle may momentarily drop to 8V. This is normal.




### 2. CUT-OUT FOR GAUGE

- RPM Gauge : Ø 86 mm
- Coolant Temperature Gauge : Ø 53 mm
- Battery Volt Meter Gauge : Ø 53 mm
- Ignition Key : Ø 57 mm

### 3. CUT-OUT FOR EOI SYSTEM

- You can use the installation template enclosed with EOI for a cut-out.



※ Hatching : Cutting area

4. SEASLINK PRODUCT COMPONENTS

1) SeasLINK Dongle



Bluetooth 4.0  
communication



2) Smart phone application  
"SeasLINK"



WIFI or Mobile Network



3) Web site  
" seaslink.hyundai-seasall.com"



### 5. INSTALLATION OF SEASLINK DONGLE

Install the SeasLINK dongle for communication between the engine and your smart phone. The dongle should be installed on the diagnosis connector (OBD Terminal) of the EOI. If you use the diagnosis tool, PLEASE REMOVE SEASLINK DONGLE.



SeasLINK Dongle



S2/S/D/U Engine



H/L Engine


### 5.1 DOWNLOAD APPLICATION

- 1) Android (Search word at Play Store : **seaslink**)
  - At least android OS version Kitkat (4.4.2)
  - Check : Settings → About phone → Software information

- 2) iPhone (Search word at App Store : **seaslink**)
  - At least iPhone 4S

### 5.2 CREATE AN ACCOUNT

1. Access on web page
  - Visit our website on your PC or smart phone  
"seaslink.hyundai-seasall.com"



2. Create ID/PW
  - Click 'Create an account' icon and create your account. ID and PW will be used for the application.



3. SeasLINK login
  - Input ID and PW on your smart phone application.









CHAPTER 9

EOI SYSTEM

The Engine Operating Indicator (EOI) system gives you a lot of information about the engine’s current status. You can hear alarm beeps, or see information including RPM, coolant temperature, warning lamps, error codes and engine working time. If the switch is on, warning lamps for battery, engine oil and so on will flash. When the engine starts normally, the lamps all go off. If there is a problem, the specific lamp will come on. You should contact your nearest Hyundai SeasAll dealer and have the engine checked as soon as possible.

1. OVERVIEW OF EOI SYSTEM

Engine Operating Indicator



TOTAL FULL RUNNING TIME

rpm



l/h

°C


V

%


Hr




HYUNDAI SEASALL




Engine Check Lamp




Low Battery Lamp




Low Oil Pressure Lamp  
(pressure < 0.5bar)





Water Sensor Lamp  
( Water in Fuel )



Alarm reset button



LCD Display Brightness Control  
button




Function button  
(operation information LCD)

1.1 INFORMATION LCD ITEM

TOTAL FULL RUNNING TIME

DTC

 Neut

rpm

l/h

°C

V

%

Hr

rpm

1680

● Engine RPM  
: 1680 RPM

°C

93.8

● Coolant temperature  
: 93.8 °C

%

70

● Throttle Lever position  
: 70%

l/h

15.7

● Fuel Consumption  
: 15.7 l/h

V

13.8

● Battery Voltage  
: 13.8V

RUNNING TIME

Hr

1.5

● Running Time after  
Key-on : 1.5 Hr

WOT RUNNING TIME

Hr


26

● Total WOT Accumulated  
Running Time : 26 Hr

DTC

P0087

● Diagnostic Trouble Code  
: P0087

 Neut

● Warning Lever on  
Neutral

### 1.2 SWITCHES

- Buzzer Reset Switch - This switch is used for turning off the alarm temporarily.
- Dimmer Switch - This switch is used for controlling brightness of the other gauges connected to the EOI.
- Function Switch - This switch is used for changing the information display on the LCD.

### 1.3 ALARM LAMPS

Alarm may sound when alarm lamps flicker.

#### CHECK ENGINE LAMP



- This lamp informs you that the engine has a serious problem.
- You can see the DTC on the LCD of the EOI.
- It may be possible to drive at limited rpm. The ECU will control the functions to protect the engine. You should immediately have the engine checked at the nearest service shop.

#### ENGINE OIL LAMP



- This lamp informs you of the engine oil pressure low.
- If this lamp is on, you should stop the engine and check the oil level with oil gauge. If the oil is low, refill it. If you refill the oil and the lamp still does not turn off, you should ask your local service shop for maintenance.

#### ALTERNATOR LAMP




- This lamp informs you to recharge your battery.
- If this lamp is turned on, you should stop the engine and eliminate electric load, as well as check the alternator, alternator drive belt and wiring system.

#### WATER SENSOR LAMP



- This lamp informs you to extract water from fuel filter.
- If the lamp is on, you should stop the engine immediately and drain the water in the fuel filter.
- It is recommended to check and drain the water in the fuel filter at regular periods before the lamp turns on.
- It can be harmful to drive your engine with this lamp on.

### 2. EOI CONNECTIONS



- |                                                |                                         |
|------------------------------------------------|-----------------------------------------|
| 1. Connection plug – CN1 (from engine)         | 6. Connection plug – CN6 (service tool) |
| 2. Connection plug – CN2 (to dual EOI)         | 7. Connection plug – CN7 (external)     |
| 3. Connection plug – CN3 (tachometer)          | 8. Connection plug – CN8 (key box)      |
| 4. Connection plug – CN4 (coolant temp. gauge) | 9. System power fuse (3 amp)            |
| 5. Connection plug – CN5 (volt gauge)          | 10. Buzzer                              |

※ It can be connected to the CN6 of EOI box as well as G-scan connector in the ECU box.



### WARNING

**LISTEN FOR A CLICK WHEN FASTENING CONNECTORS.  
THIS SOUND INDICATES THAT THEY ARE SECURELY LOCKED**




### CAUTION

**DON'T CONNECT EXTRA INSTRUMENTS WHICH DRAW MORE  
THAN 1 AMPERE. THE E.O.I WILL BE OVERLOADED AND DAMAGED**


### 3. EOI PIN ASSIGNMENT

#### CN1 (MAIN EOI CONNECTOR FROM ENGINE)



- |                               |                     |
|-------------------------------|---------------------|
| 1. Ignition power             | 13. RPM signal      |
| 2. Main relay power           | 14. Spare           |
| 3. Permanent power            | 15. Spare           |
| 4. Not used                   | 16. Spare           |
| 5. Not used                   | 17. Neutral signal  |
| 6. Coolant temperature signal | 18. K line          |
| 7. Not used                   | 19. CAN_L           |
| 8. Check lamp                 | 20. Changing signal |
| 9. Oil pressure signal        | 21. CAN_H           |
| 10. Ground                    | 22. Not used        |
| 11. Not used                  | 23. Ground          |
| 12. Water detection signal    | 24. Not used        |

#### CN2 (DUAL EOI CONNECTOR)




- |                            |                     |
|----------------------------|---------------------|
| 1. Ignition power          | 13. RPM signal      |
| 2. Main relay power        | 14. Spare           |
| 3. Permanent power         | 15. Spare           |
| 4. Not used                | 16. Spare           |
| 5. Not used                | 17. Neutral signal  |
| 6. Not used                | 18. K line          |
| 7. Not used                | 19. CAN_L           |
| 8. Check lamp              | 20. Changing signal |
| 9. Oil pressure signal     | 21. CAN_H           |
| 10. Ground                 | 22. Not used        |
| 11. Not used               | 23. Ground          |
| 12. Water detection signal | 24. Not used        |




### CN3 (TACHOMETER)

1. Main relay power
2. RPM signal
3. Ground
4. Illumination
5. Illumination
6. CAN\_H
7. CAN\_L
8. Not used




### CN4 (COOLANT TEMP. GAUGE)

1. Coolant temperature signal
2. Ignition power
3. Ground
4. Illumination
5. Illumination
6. Not used




### CN5 (VOLTMETER)

1. Ignition power
2. Ground
3. Illumination
4. Illumination




### CN6 (SERVICE TOOL)

1. CAN\_H
2. CAN\_L
3. K\_line
4. Ground
5. Main relay power
6. Not used




### CN7 (EXTERNAL)

1. Ground
2. Permanent power
3. Ignition power
4. Neutral switch
5. Neutral switch
6. Charging signal
7. RPM signal
8. Dimmer



### CN8 (KEY BOX)


1. Ignition power
2. Start power
3. Permanent power




### 4. NEUTRAL SWITCH AND DUAL EOI CONNECTION

- 1) Neutral switch wires should be connected at pin #4 and #5 of the external connector of the EOI. If there is no neutral switch, jumper #4 and #5 with short wiring.

#### SYSTEM WITH A NEUTRAL SWITCH




#### SYSTEM WITH NO NEUTRAL SWITCH




- 2) If there is a dual EOI, you should connect the wiring between #5 (external connector of the main EOI) and #5 (external connector of the dual EOI)

#### Main EOI external connector



From neutral switch wiring


#### Dual EOI external connector



### CAUTION

FOR USER'S SAFETY, ENGINE WILL NOT CRANK OR START IF GEAR POSITION LEVER IS NOT IN NEUTRAL OR NOT CONNECTED TO THE EOI EXTERNAL CONNECTION.

### 5. TRIM WIRING CONNECTION DIAGRAM









- |   |                                  |   |                                         |
|---|----------------------------------|---|-----------------------------------------|
| 1 | REMOTE CONTROL                   | 8 | TRANSOM PLATE                           |
| 2 | TRAILER SWITCH                   | 9 | GEAR LUBE MONITOR                       |
| 3 | GAUGE-TRIM                       | A | WIRING-REMOTE CONTROL : 00112-2H122/5   |
| 4 | GAUGE-VOLT                       | B | WIRING-GAUGE & LAMP : 00112-2H123 (5EA) |
| 5 | EOI                              | C | WIRING-BATTERY GROUND : 00122-2H121     |
| 6 | BUZZER (DRIVE OIL) : 00113-1A152 | D | WIRING-BATTERY-VOLT : 00112-5S114       |
| 7 | TRIM PUMP                        |   |                                         |

\* SWITCH of the SeaStar's controller models **CH1752P**, **CH7552P**, **CH7842P** are included within its package.

Trailer Switch not included. (Switch-Trim Limite A/B terminal must be modified)

5.1 GAUGE & LAMP WIRING CONNECTION DIAGRAM



| RPM                                                                                | Battery Voltmeter                                                                   | Coolant Temp.                                                                       | Key Switch                                                                           | Trim<br>(Stern drive)                                                                 |
|------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|
|  |  |  |  |  |
| ① MAIN<br>② OUT<br>③ AUX                                                           | ① GND<br>② IG_POWER<br>③ DIMMER<br>④ LAMP<br>⑤ SIGNAL                               | ① GND<br>② IG_POWER<br>③ DIMMER<br>④ LAMP<br>⑤ SIGNAL                               | ① BATTERY(+)<br>② START<br>③ IG_POWER                                                | ① GND<br>② IG_POWER<br>③ DIMMER<br>④ LAMP<br>⑤ SIGNAL                                 |

### 6. G-SCAN


The G-SCAN is a diagnostic tool which dealers can use for DTC analysis, fault code searches, data analysis and ECU upgrades.



#### 6-1. G-SCAN CONNECTIONS

G-scan can be connected to the CN6 connector of EOI, as well as G-scan connector in the ECU box. For information about the CN6 of EOI, please refer to Chapter 9.

※ When the G-SCAN is connected, the EOI cannot be used to communicate with the engine. When using the G-Scan, the SeasLINK dongle must be unplugged.





# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

### 7. ALARM AND DTC (DIAGNOSIS TROUBLE CODE)

If there is a problem in the engine, the EOI display (audible or visible) alarm and related DTC (diagnosis trouble code) will give you information about it. The DTC display is only for initial assistance and to aid communication with a Hyundai SeasAll dealer if there is an emergency. You should contact your nearest Hyundai SeasAll dealer as soon as possible if a system problem arises.

#### 7.1 ALARM LIST

Note 1) RPM Limit : ● ( Rated rpm - 500rpm), ○ (Rated rpm - 800rpm)

Note 2),3) would be applied to S250/220 models

| Item                               | DTC                                  | Description                                                                                | Fail safety        |                   | Alarm |        | Expectation Cause(s)                                                                                                                          |  |
|------------------------------------|--------------------------------------|--------------------------------------------------------------------------------------------|--------------------|-------------------|-------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------|--|
|                                    |                                      |                                                                                            | Fuel cut off       | Note 1) RPM limit | Lamp  | Buzzer |                                                                                                                                               |  |
| VGT variable geometry turbocharger | P2263<br>P2268<br>P226(5/6)<br>P2267 | GPA failure<br>[PWM failed, Positioning failed, Operating range failed(UMS/LMS), Overheat] | -                  | ○                 |       | √      | • Overload, VGT cooling circuit<br>• VGT actuator adaption error<br>• VGT actuator performance error                                          |  |
|                                    | P2563                                | Pwm line Failure                                                                           |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0048                                | Short circuit battery                                                                      |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0047                                | Short circuit ground                                                                       | -                  |                   |       | √      | • VGT actuator circuit<br>• VGT actuator                                                                                                      |  |
|                                    |                                      | No Load                                                                                    |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0234                                | Boost pressure higher than target value                                                    |                    |                   |       |        | • VGT actuator performance error                                                                                                              |  |
|                                    | P0299                                | Boost pressure lower than target value                                                     | -                  |                   |       | √      | • Air leakage check<br>• Intercooler<br>• VGT actuator performance error                                                                      |  |
| APS1 acceleration position sensor1 | P2138                                | Plausibility With Aps2 Violated                                                            | -                  | 1250 rpm fixed    |       | √      | • APS1/2 sensor circuit<br>• APS sensor<br>• ECM (engine control module)                                                                      |  |
|                                    | P2127                                | Voltage Above Lower Limit                                                                  |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P2123                                | Voltage Above Upper Limit                                                                  |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0643                                | Supply Voltage Above Upper Limit                                                           |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0642                                | Supply Voltage Below Lower Limit                                                           |                    |                   |       |        |                                                                                                                                               |  |
| APS2 acceleration position sensor2 | P2128                                | Voltage above upper limit                                                                  |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0653                                | Supply voltage above upper limit                                                           |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0652                                | Supply voltage below lower limit                                                           |                    |                   |       |        |                                                                                                                                               |  |
| CMPS cam position sensor           | P0340                                | No camshaft signal                                                                         | √<br>(at starting) | ●                 |       | √      | • CMPS circuit<br>• CMPS                                                                                                                      |  |
|                                    | P0341                                | Wrong camshaft signal                                                                      |                    |                   |       |        |                                                                                                                                               |  |
| CKPS crank position sensor         | P0335                                | No crankshaft signal (engine running)                                                      | √                  | -                 |       | √      | • CKPS circuit<br>• CKPS<br>• Target wheel check                                                                                              |  |
|                                    | P0336                                | Wrong crankshaft signal (restart)                                                          |                    |                   |       |        |                                                                                                                                               |  |
| Water detection in fuel            | P2264                                | Water in fuel is detected                                                                  | -                  | ●                 |       | √      | • Water in fuel, fuel filter<br>(drain out water and check the fuel in fuel tank)<br>• Warning lamp circuit<br>• Water detection sensor error |  |
| Cylinder1 injector                 | P0201                                | Open load                                                                                  |                    | ○                 |       | √      | • Injector circuit<br>• Injector                                                                                                              |  |
|                                    | P0261                                | Short circuit ground                                                                       | √                  | -                 |       |        |                                                                                                                                               |  |
|                                    | P0262                                | Short circuit battery                                                                      |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0263                                | Defect resistance cylinder1, Charging/discharging energy error                             | -                  |                   |       |        |                                                                                                                                               |  |
| Cylinder2 injector                 | P0202                                | Open load                                                                                  |                    | ○                 |       | √      | • Injector circuit<br>• Injector                                                                                                              |  |
|                                    | P0264                                | Short circuit ground                                                                       | √                  | -                 |       |        |                                                                                                                                               |  |
|                                    | P0265                                | Short circuit battery                                                                      |                    |                   |       |        |                                                                                                                                               |  |
|                                    | P0266                                | Defect resistance cylinder1, Charging/discharging energy error                             | -                  |                   |       |        |                                                                                                                                               |  |



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

HYUNDAI SEASALL





| Item                       | DTC   | Description                                                    | Fail safety  |                   | Alarm |        | Possible Cause(s)                                                                             |  |
|----------------------------|-------|----------------------------------------------------------------|--------------|-------------------|-------|--------|-----------------------------------------------------------------------------------------------|--|
|                            |       |                                                                | Fuel cut off | Note 1) RPM limit | Lamp  | Buzzer |                                                                                               |  |
| Cylinder3 injector         | P0203 | Open load                                                      |              | ○                 |       | √      | • Injector circuit<br>• Injector                                                              |  |
|                            | P0267 | Short circuit ground                                           | √            |                   |       |        |                                                                                               |  |
|                            | P0268 | Short circuit battery                                          |              |                   |       |        |                                                                                               |  |
|                            | P0269 | Defect resistance cylinder1, Charging/discharging energy error | -            | -                 |       |        |                                                                                               |  |
| Cylinder4 injector         | P0204 | Open load                                                      |              | ○                 |       | √      | • Injector circuit<br>• Injector                                                              |  |
|                            | P0270 | Short circuit ground                                           | √            |                   |       |        |                                                                                               |  |
|                            | P0271 | Short circuit battery                                          |              |                   |       |        |                                                                                               |  |
|                            | P0272 | Defect resistance cylinder1, Charging/discharging energy error | -            | -                 |       |        |                                                                                               |  |
| Note 2) Cylinder5 injector | P0205 | Open load                                                      |              | ○                 |       | √      | • Injector circuit<br>• Injector                                                              |  |
|                            | P0273 | Short circuit ground                                           | √            |                   |       |        |                                                                                               |  |
|                            | P0274 | Short circuit battery                                          |              |                   |       |        |                                                                                               |  |
|                            | P0275 | Defect resistance cylinder1, Charging/discharging energy error | -            | -                 |       |        |                                                                                               |  |
| Note 3) Cylinder6 injector | P0206 | Open load                                                      |              | ○                 |       | √      | • Injector circuit<br>• Injector                                                              |  |
|                            | P0276 | Short circuit ground                                           | √            |                   |       |        |                                                                                               |  |
|                            | P0277 | Short circuit battery                                          |              |                   |       |        |                                                                                               |  |
|                            | P0278 | Defect resistance cylinder1, Charging/discharging energy error | -            | -                 |       |        |                                                                                               |  |
| Injector Bank Error        | P062D | Bank 1 error                                                   | √            | -                 |       | √      | • Charging system (battery, alternator check)<br>• ECM                                        |  |
|                            | P062E | Bank 2 error                                                   |              |                   |       |        |                                                                                               |  |
| Injectors Circuit          | P0611 | Error path for short circuit of charging switch is detected    | √            | -                 |       | √      | • Injectors circuit<br>• ECM                                                                  |  |
|                            | P0200 | Injector circuit error                                         |              |                   |       |        |                                                                                               |  |
| RPS rail pressure sensor   | P0193 | Voltage above upper limit                                      | -            | ●                 |       | √      | • PRS circuit<br>• PRS<br>• APS 2 power supply circuit<br>• BPS power supply circuit<br>• ECM |  |
|                            | P0192 | Voltage below lower limit                                      |              |                   |       |        |                                                                                               |  |
|                            | P0653 | Supply voltage above upper limit                               |              |                   |       |        |                                                                                               |  |
|                            | P0652 | Supply voltage below lower limit                               |              |                   |       |        |                                                                                               |  |
| Rail pressure Monitoring   | P0087 | Maximum positive deviation of rail pressure exceeded           | -            | ○                 |       | √      | • Fuel filter<br>• RPS check<br>• P-PRV , PRV check(stuck)                                    |  |
|                            | P0088 | Maximum negative deviation of rail pressure exceeded           |              |                   |       |        |                                                                                               |  |
|                            | P1171 | Minimum rail pressure exceeded                                 | √            | -                 |       |        |                                                                                               |  |
|                            | P1172 | Maximum rail pressure exceeded                                 | -            | ○                 |       |        |                                                                                               |  |
| BPS boost pressure sensor  | P0238 | Voltage above upper limit                                      | -            | ●                 |       | √      | • BPS circuit<br>• BPS<br>• RPS power supply circuit<br>• APS 2 power supply circuit<br>• ECM |  |
|                            | P0237 | Voltage below lower limit                                      |              | -                 |       |        |                                                                                               |  |
|                            | P0069 | Not plausible with atmospheric pressure sensor                 |              | -                 | -     | -      |                                                                                               |  |
|                            | P0653 | Supply voltage above upper limit                               |              | ●                 |       | √      |                                                                                               |  |
|                            | P0652 | Supply voltage below lower limit                               |              | -                 |       |        |                                                                                               |  |



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

HYUNDAI SEASALL

| Item                                      | DTC   | Description                                               | Fail safety  |                      | Alarm                                                                             |        | Possible Cause(s)                                                                                              |
|-------------------------------------------|-------|-----------------------------------------------------------|--------------|----------------------|-----------------------------------------------------------------------------------|--------|----------------------------------------------------------------------------------------------------------------|
|                                           |       |                                                           | Fuel cut off | Note 1)<br>RPM limit | Lamp                                                                              | Buzzer |                                                                                                                |
| PPRV<br>pump pressure<br>regulator valve  | P0254 | Short circuit to battery of metering unit output          | -            | ○                    |  | √      | <ul style="list-style-type: none"> <li>• P-PRV circuit</li> <li>• P-PRV</li> </ul>                             |
|                                           | P0253 | Short circuit to ground of metering unit output           | √            | -                    |                                                                                   |        |                                                                                                                |
|                                           |       | Open load of metering unit output                         | -            | ○                    |                                                                                   |        |                                                                                                                |
|                                           | P0252 | Powerstage error                                          | -            | ○                    |                                                                                   |        |                                                                                                                |
| PRV<br>(rail) pressure<br>regulator valve | P0092 | Short circuit to battery of pressure control valve output | √            | -                    |  | √      | <ul style="list-style-type: none"> <li>• PRV circuit</li> <li>• PRV</li> </ul>                                 |
|                                           | P0091 | Short circuit to ground of pressure control valve output  |              |                      |                                                                                   |        |                                                                                                                |
|                                           |       | Open load of pressure control valve output                |              |                      |                                                                                   |        |                                                                                                                |
|                                           | P0089 | Powerstage error                                          |              |                      |                                                                                   |        |                                                                                                                |
| OPS<br>oil pressure<br>sensor             | -     | Oil pressure low (below 0.8 bar)                          | -            | -                    |  | √      | • Oil switch, Oil level, Circuit check                                                                         |
| Charging Error                            | -     | Charging system error                                     | -            | -                    |  | √      | • Alternator, Charging circuit check                                                                           |
| E(C)TS<br>engine coolant<br>temp. sensor  | -     | Coolant temperature high (above 110°C)                    | -            | Depending<br>temp.   | EOI LCD<br>Blinking                                                               | √      | <ul style="list-style-type: none"> <li>• ECTS circuit</li> <li>• ECTS</li> <li>• Cooling line check</li> </ul> |



## 7.2 DTC(DIAGNOSIS TROUBLE CODE) LIST

| NO | P code | DESCRIPTION                                                  |
|----|--------|--------------------------------------------------------------|
| 1  | P0016  | Crankshaft Position – Camshaft Position Correlation          |
| 2  | P0047  | Turbocharger Boost Control Solenoid Circuit Low              |
| 3  | P0048  | Turbocharger Boost Control Solenoid Circuit High             |
| 4  | P0069  | Manifold Absolute Pressure – Barometric Pressure Correlation |
| 5  | P0087  | Fuel Rail/System Pressure - Too Low                          |
| 6  | P0088  | Fuel Rail/System Pressure - Too High                         |
| 7  | P0089  | Fuel Pressure Regulator 1 Performance                        |
| 8  | P0091  | Fuel Pressure Regulator 1 Control Circuit Low                |
| 9  | P0092  | Fuel Pressure Regulator 1 Control Circuit High               |
| 10 | P0097  | Intake Air Temperature Sensor 2 Circuit Low                  |
| 11 | P0098  | Intake Air Temperature Sensor 2 Circuit High                 |
| 12 | P0107  | Atmospheric Pressure Sensor Voltage Lower Limit              |
| 13 | P0108  | Atmospheric Pressure Sensor Voltage Upper Limit              |
| 14 | P0112  | Intake Air Temperature Sensor1 Circuit Low Input             |
| 15 | P0113  | Intake Air Temperature Sensor1 Circuit High Input            |
| 16 | P0116  | Engine Coolant Temperature Circuit Range / Performance       |
| 17 | P0117  | Engine Coolant Temperature Circuit Low Input                 |
| 18 | P0118  | Engine Coolant Temperature Circuit High Input                |
| 19 | P0182  | Fuel Temp Sensor A Circuit Low Input                         |
| 20 | P0183  | Fuel Temp Sensor A Circuit High Input                        |
| 21 | P0192  | Fuel Rail Pressure Sensor Circuit Low input                  |
| 22 | P0193  | Fuel Rail Pressure Sensor Circuit High Input                 |
| 23 | P0194  | Fuel Rail Pressure Sensor Circuit Intermittent               |
| 24 | P0200  | Injector Circuit Error                                       |
| 25 | P0201  | Cylinder 1 Injector Open Load                                |
| 26 | P0202  | Cylinder 2 Injector Open Load                                |
| 27 | P0203  | Cylinder 3 Injector Open Load                                |
| 28 | P0204  | Cylinder 4 Injector Open Load                                |
| 29 | *P0205 | Cylinder 5 Injector Open Load                                |
| 30 | *P0206 | Cylinder 6 Injector Open Load                                |
| 31 | P0231  | Fuel Pump Secondary Circuit Low                              |



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

| NO | P code | DESCRIPTION                                            |
|----|--------|--------------------------------------------------------|
| 32 | P0232  | Fuel Pump Secondary Circuit High                       |
| 33 | P0234  | Turbocharger Over boost Condition                      |
| 34 | P0237  | Turbocharger Boost Sensor "A" Circuit Low              |
| 35 | P0238  | Turbocharger Boost Sensor "A" Circuit High             |
| 36 | P0252  | Pump Pressure Regulation Valve Circuit                 |
| 37 | P0253  | Pump Pressure Regulation Valve Circuit Low             |
| 38 | P0254  | Pump Pressure Regulation Valve Circuit High            |
| 39 | P0261  | Cylinder 1 - Injector Circuit Low                      |
| 40 | P0262  | Cylinder 1 - Injector Circuit High                     |
| 41 | P0263  | Cylinder 1 Contribution/Balance                        |
| 42 | P0264  | Cylinder 2 - Injector Circuit Low                      |
| 43 | P0265  | Cylinder 2 - Injector Circuit High                     |
| 44 | P0266  | Cylinder 2 Contribution/Balance                        |
| 45 | P0267  | Cylinder 3 - Injector Circuit Low                      |
| 46 | P0268  | Cylinder 3 - Injector Circuit High                     |
| 47 | P0269  | Cylinder 3 Contribution/Balance                        |
| 48 | P0270  | Cylinder 4 - Injector Circuit Low                      |
| 49 | P0271  | Cylinder 4 - Injector Circuit High                     |
| 50 | P0272  | Cylinder 4 Contribution/Balance                        |
| 51 | *P0273 | Cylinder 5 - Injector Circuit Low                      |
| 52 | *P0274 | Cylinder 5 - Injector Circuit High                     |
| 53 | *P0275 | Cylinder 5 Contribution/Balance                        |
| 54 | *P0276 | Cylinder 6 - Injector Circuit Low                      |
| 55 | *P0277 | Cylinder 6 - Injector Circuit High                     |
| 56 | *P0278 | Cylinder 6 Contribution/Balance                        |
| 57 | P0299  | Turbocharger Under boost                               |
| 58 | P0300  | Random/Multiple Cylinder Misfire Detected              |
| 59 | P0335  | Crankshaft Position Sensor A Circuit                   |
| 60 | P0336  | Crankshaft Position Sensor A Circuit Range/Performance |
| 61 | P0340  | Camshaft Position Sensor A Circuit Malfunction         |



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

HYUNDAI SEASALL

| NO | P code | DESCRIPTION                                              |
|----|--------|----------------------------------------------------------|
| 62 | P0341  | Camshaft Position Sensor A Circuit Range/Performance     |
| 63 | P0381  | Glow Plug/Heater Indicator Circuit                       |
| 64 | P0562  | System Voltage Low                                       |
| 65 | P0563  | System Voltage High                                      |
| 66 | P0601  | Internal Control Module Memory Check Sum Error           |
| 67 | P0602  | Control Module Programming Error                         |
| 68 | P0604  | Internal Control Module Random Access Memory (RAM) Error |
| 69 | P0605  | Internal Control Module Read Only Memory(ROM) Error      |
| 70 | P0606  | ECM/PCM Processor                                        |
| 71 | P0611  | Injector Circuit Error                                   |
| 72 | P062D  | Injector Bank1 Error                                     |
| 73 | P062E  | Injector Bank2 Error                                     |
| 74 | P0642  | Sensor Reference Voltage "A" Circuit Low                 |
| 75 | P0643  | Sensor Reference Voltage "A" Circuit High                |
| 76 | P0650  | Malfunction Indicator Lamp(MIL) Control Circuit          |
| 77 | P0652  | Sensor Reference Voltage "B" Circuit Low                 |
| 78 | P0653  | Sensor Reference Voltage "B" Circuit High                |
| 79 | *P0670 | Glow Plug Module Control Circuit                         |
| 80 | *P0671 | Cylinder 1 Glow Plug Circuit                             |
| 81 | *P0672 | Cylinder 2 Glow Plug Circuit                             |
| 82 | *P0673 | Cylinder 3 Glow Plug Circuit                             |
| 83 | *P0674 | Cylinder 4 Glow Plug Circuit                             |
| 84 | *P0675 | Cylinder 5 Glow Plug Circuit                             |
| 85 | *P0676 | Cylinder 6 Glow Plug Circuit                             |
| 86 | *P0683 | Glow Control Module Signal                               |
| 87 | *P0684 | Glow Control Module Performance                          |
| 88 | P0685  | ECM/PCM Power Relay Control Circuit /Open                |
| 89 | *P0698 | Variable Swirl Actuator Voltage Lower Limit              |
| 90 | *P0699 | Variable Swirl Actuator Voltage Upper Limit              |
| 91 | P1145  | Overrun Monitoring                                       |



| NO  | P code | DESCRIPTION                                                              |
|-----|--------|--------------------------------------------------------------------------|
| 92  | P1171  | Minimum Rail Pressure Exceeded                                           |
| 93  | P1172  | Maximum Rail Pressure Exceeded                                           |
| 94  | P1173  | Set Value of PCV not in Plausibility Range                               |
| 95  | P1185  | Maximum Pressure Exceeded                                                |
| 96  | P1186  | Minimum Pressure at Engine Speed Too Low                                 |
| 97  | P1187  | Regulator Valve Stick                                                    |
| 98  | P1188  | Leakage                                                                  |
| 99  | P1307  | Acceleration Sensor Range/Performance                                    |
| 100 | P1308  | Acceleration Sensor Circuit Low Input                                    |
| 101 | P1309  | Acceleration Sensor Circuit High Input                                   |
| 102 | P1325  | Glow Relay Malfunction                                                   |
| 103 | P1636  | Voltage Regulator for Injector                                           |
| 104 | P1652  | Ignition Key No Signal                                                   |
| 105 | P1653  | After-Run Check Error                                                    |
| 106 | P1655  | Tachometer Output Fault                                                  |
| 107 | P1670  | Invalid Injector IQA/C2I                                                 |
| 108 | P1671  | Injector IQA Checksum Error                                              |
| 109 | P1679  | EMS Data Fail (Data frame, CS, Message error)                            |
| 110 | P1694  | EMS Message Error                                                        |
| 111 | P1695  | EMS Memory Error                                                         |
| 112 | P1697  | HI-SCAN message Error                                                    |
| 113 | *P2009 | Variable Swirl Actuator Control Circuit Low(Bank 1)                      |
| 114 | *P2010 | Variable Swirl Actuator Control Circuit High(Bank 1)                     |
| 115 | *P2015 | Variable Swirl Actuator Position Sensor/Switch Circuit Range/Performance |
| 116 | *P2016 | Variable Swirl Actuator Position Sensor/Switch Circuit Low               |
| 117 | *P2017 | Variable Swirl Actuator Position Sensor/Switch Circuit High              |
| 118 | P2122  | Throttle/Pedal Position Sensor/Switch "D" Circuit Low Input              |
| 119 | P2123  | Throttle/Pedal Position Sensor/Switch "D" Circuit High Input             |
| 120 | P2127  | Throttle/Pedal Position Sensor/Switch "E" Circuit Low Input              |
| 121 | P2128  | Throttle/Pedal Position Sensor/Switch "E" Circuit High Input             |

| NO  | P code | DESCRIPTION                                                              |
|-----|--------|--------------------------------------------------------------------------|
| 122 | P2138  | Throttle/Pedal Position Sensor/Switch "D" / "E" Voltage Correlation      |
| 123 | P2228  | Barometric Pressure Circuit Low Input                                    |
| 124 | P2229  | Barometric Pressure Circuit High Input                                   |
| 125 | P2262  | Turbocharger Boost Pressure Not Detected - Mechanical                    |
| 126 | P2263  | Turbocharger Boost System Performance                                    |
| 127 | P2265  |                                                                          |
| 128 | P2266  |                                                                          |
| 129 | P2267  |                                                                          |
| 130 | P2268  |                                                                          |
| 131 | P2264  | Water in Fuel Sensor Circuit                                             |
| 132 | *P2562 | Turbocharger Boost Control Position Sensor "A" Circuit                   |
| 133 | *P2563 | Turbocharger Boost Control Position Sensor "A" Circuit Range/Performance |
| 134 | *P2564 | Turbocharger Boost Control Position Sensor "A" Circuit Low               |
| 135 | *P2565 | Turbocharger Boost Control Position Sensor "A" Circuit High              |
| 136 | *P2566 | Turbocharger Boost Control Position Sensor "A" Circuit Intermittent      |
| 137 | U0001  | Abnormal communication signals (CAN)                                     |
| 138 | U0100  | No communication signals (CAN)                                           |

\*Pxxxx codes apply to S250 and S270 models



CHAPTER 10  
ANTI CORROSION SYSTEM



Sacrificial anodes

- 1) Sacrificial anode must be replaced every 250 hours or if more than 60% has been used.
- 2) Check especially frequently when used in saltwater. It is recommended to replace the sacrificial anodes at the start of each season.




**CAUTION**

- DON'T OPERATE ENGINE WITHOUT ANODES. IT IS HARMFUL TO YOUR ENGINE.
- CLOSE THE SEAWATER VALVE BEFORE THIS MAINTENANCE.
- MAKE SURE TO CHECK THE ANODE PLUG IN ACCORDANCE WITH THIS MANUAL; DON'T LOOSEN COOLANT DRAIN PLUG.

### CHAPTER 11

### ENGINE OPERATION

#### 1. ENGINE ON/OFF



- 1) Before starting the engine, you should check engine oil, coolant, gearbox oil, fuel gauge, seawater pump, battery, seacocks and so on.
- 2) When you start the engine, check that the engine throttle lever① is in the neutral position. If not, the engine may not start or there is possibility of the boat moving inadvertently. If your boat is equipped with a neutral safety switch, the engine will only crank when the engine throttle lever is in the neutral position. You can also check this on the EOI.
- 3) After starting the engine, release the key② immediately to prevent damage to the starter motor.
- 5) Avoid maximum rpm and WOT (Wide Open Throttle) before the cold engine is fully warmed up.
- 6) When cold starting, it may take a few more seconds to start the engine.
- 7) If the engine does not start in 10 seconds, release the key and wait 10 seconds. After 10 seconds try again. This method can help avoid starter motor damage.



### WARNING

**DO NOT DRIVE IN SPACE WHERE THERE IS NO AIR CIRCULATION.  
EMISSION GAS IS HARMFUL.**

## 2. ENGINE BREAK-IN

### Initial Break-in Procedure

The first 20 hours of operation is the engine break-in period. During this period, it is important that the engine is operated as outlined below.

- 1) DO NOT operate engine at idle rpm for extended periods of time during the first 10 hours.
- 2) DO NOT operate at any one constant speed for extended periods of time.
- 3) DO NOT exceed 75% of full throttle during the first 10 hours. After the next 10 hours, occasional operation at full throttle (5 minutes at a time maximum) is permissible.
- 4) AVOID full throttle accelerations from neutral position.
- 5) DO NOT operate at all full throttle until engine reaches normal operating temperature.
- 6) FREQUENTLY CHECK engine oil level and add oil if necessary.

## 3. STOPPING THE ENGINE

The engine should be run for a few minute at idle (in neutral) before turning it off. This will avoid boiling the cooling system and even out the temperature.

This is especially important if the engine has been operated at high engine speeds and/or with heavy loads.

Shutting down the engine in this fashion will extend the life of your engine.




### WARNING

**DO NOT OPERATE IN SPACES WHERE THERE IS NO AIR CIRCULATION.  
EXHAUST GAS IS HARMFUL.**

### 4. EMERGENCY STOP

- 1) You can stop the engine by pushing this button. After releasing the switch, you can start the engine again. (Normally, the button should be in the “out” position.)
- 2) When the button is pressed or it doesn't work normally, the engine won't crank. We recommend that you check this switch first if there is any cranking problem.
- 3) You can use this switch to avoid unexpected engine starting during maintenance.
- 4) You can use this switch for any emergency situation when you want to stop the engine.

Engine stop Switch



### CHAPTER 12

### ENGINE STORAGE

The major consideration in preparing your engine for storage is to protect it from rust, corrosion, and damage caused by freezing of trapped water.

The following storage procedures should be followed to prepare your engine for out-of-season storage or prolonged storage (two months or longer and/or winter storage) :

| CHECK LIST                                                                                                                                                                                           |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| • Visual inspection for leaks and damage                                                                                                                                                             |
| • Change engine oil and oil filter                                                                                                                                                                   |
| • Replace fuel filter                                                                                                                                                                                |
| • Check air filter element and clean if necessary                                                                                                                                                    |
| • Check engine coolant level and top up if necessary                                                                                                                                                 |
| • Check impeller for wear. If in good condition, remove and store in a dark, dry place. If replacement is required, prepare a new impeller to be installed when the engine is put back into service. |
| • Check anode and replace if necessary                                                                                                                                                               |
| • Clean the engine                                                                                                                                                                                   |
| • Flush and drain seawater cooling system                                                                                                                                                            |
| • Fill fuel tank until full and inspect the fuel system                                                                                                                                              |
| • Remove the battery and store in a cool, dry place                                                                                                                                                  |



### CAUTION

**FOR OVER-WINTERING, SEAWATER SHOULD BE DRAINED FULLY BY LOOSENNING HEAT EXCHAGER ANODE. REFER TO CHAPTER 10.**

### WINTER STORAGE

Protect your engine from freezing and corrosion damage by following the procedures indicated below.

#### • LUBRICATION SYSTEM

- Start the engine and allow it to reach normal operating temperature.
- Turn off the engine. Drain the engine oil using the oil extraction pump. If the oil extraction pump is not installed, drain oil by removing the oil pan drain plug.
- Change the oil and oil filter and refill the engine with new oil according to technical maintenance specifications.
- Check the oil level on the dipstick and if necessary add more oil to reach the correct oil level.

#### • FUEL SYSTEM

- Check for fuel leaks where the line from the fuel tank connects to the engine. Tighten or replace the connection if necessary.
- Close the fuel valve. Clean the water separating fuel filter. Replace the filter element.
- After replacing the filter element, open the fuel valve to fill the entire fuel circulation line.
- Fill the fuel tank with fresh fuel to avoid condensation in the fuel tank.
- Close the fuel valve.

#### • COOLING SYSTEM

- Close the water valve.
- Connect a freshwater source to the seawater inlet. Run the engine at idle to flush all seawater out of the system.
- Fill the cooling system (seawater side) with a 30~50% solution of anti-freeze. Circulate into the seawater system by running the engine.

#### • COOLING SYSTEM

- If the seawater system is not filled with an antifreeze solution as per the instructions above, completely drain the seawater system by removing the heat exchanger and intercooler anodes.
- Check impeller for wear. If in good condition, remove and store in a dark, dry place. If replacement is required, prepare a new impeller to be installed when the engine is put back into service.
- Check all connections with inlet hoses. Tighten or replace the connection if necessary.
- Check the cooling system (heat exchanger, intercooler, thermostat, hoses, clamps, etc.) every 500 hours or every two years, whichever comes first. Replace any worn components.

#### • INTAKE SYSTEM

- Remove the air filter from engine.
- Clean the air filter.
- Intake port should be kept hermetically sealed.

#### • ELECTRICAL SYSTEM

- Disconnect the battery (-) cable to system ground
- Disconnect the battery (+) cable.
- Clean the battery cable and terminals.
- Coat the terminal connection with a battery terminal anti-corrosion agent.
- Whenever the battery will be stored for an extended period of time, be sure the cells are full of electrolyte and that the battery is fully charged.

## LONG TERM STORAGE

These instructions must be followed in order to obtain warranty coverage for long term storage engines. These procedures are intended to prevent oxidation and deterioration of engine and fuel system components.

Engines stored for more than one (1) year must be inspected properly to ensure that they are in good condition.

- Engines used within one (1) year from factory release.
  - No specific action is required.
  
- Engines stocked more than one (1) year from factory release( To check every 6 months )
  - 1) Carefully inspect & check all parts for damage and/or corrosion.
  - 2) The coolant must be replaced for long term storage. *Use 50% Glycol containing anti-corrosion additives and 50% distilled water.*
  - 3) Check *all anodes* and replace if required.
  - 4) Storage conditions should be between 15~30<sup>0</sup>C and less than 50% relative humidity.
  
- Engines for use after long term storage and/or long term inactivity.
  - 1) Carefully inspect and check all parts for damage and/or corrosion.
  - 2) The coolant and lubricants must be replaced before using the engine.
  - 3) The oil filter and fuel filter must be replaced before using the engine.
  - 4) The seawater pump impeller must be replaced before using the engine.
  - 5) The thermostat and anodes must be checked and replaced if necessary
  - 6) Crank the engine without starting to lubricate the inside of the engine. Please disconnect the Crank Position Sensor to prevent engine start while lubricating the engine.
  - 7) Run the engine 10 minutes at idle RPM with no load before putting into service.
  - 8) Refer to Pre-Delivery checklist to inspect entire engine condition and installation.

### CHAPTER 13 MAINTENANCE

#### 1. THE INITIAL RUNNING CHECK

##### - BEFORE THE WATER TEST

|                                                                     | Y | N |
|---------------------------------------------------------------------|---|---|
| Seawater inlet valve open                                           |   |   |
| Engine coolant level                                                |   |   |
| Cooling system hose clamps tight                                    |   |   |
| Engine oil level                                                    |   |   |
| Power steering fluid level                                          |   |   |
| Drive belt tension                                                  |   |   |
| All electrical connections tight                                    |   |   |
| EOI warning system operating                                        |   |   |
| Battery fully charged and secured                                   |   |   |
| All fuel connection tight                                           |   |   |
| Exhaust system hose clamps tight                                    |   |   |
| Engine mount tight                                                  |   |   |
| Engine alignment                                                    |   |   |
| Correct rotation propeller<br>(Installed and torque)                |   |   |
| Engine coolant and oil drain plug<br>closed                         |   |   |
| Throttle, shift and steering system<br>fasteners tightened properly |   |   |

##### - AFTER THE WATER TEST

|                                              |  |  |
|----------------------------------------------|--|--|
| Fuel, oil, coolant, water and fluid<br>leaks |  |  |
| Oil and fluid level                          |  |  |
| Propeller nut torque                         |  |  |

##### - ON THE WATER TEST

|                                                                   | Y | N |
|-------------------------------------------------------------------|---|---|
| Boat drain plug in place<br>(Check before putting boat in water)  |   |   |
| Seawater pump operation                                           |   |   |
| Seawater strainer correctly mounted ,<br>Clean and tightly closed |   |   |
| Engine alignment (propulsion only)                                |   |   |
| Fuel leaks                                                        |   |   |
| Oil leaks                                                         |   |   |
| Coolant leaks                                                     |   |   |
| Water leaks                                                       |   |   |
| Exhaust leaks                                                     |   |   |
| EOI and gauges operation                                          |   |   |
| Engine emergency stop switch<br>operation                         |   |   |
| Idle RPM, within specifications                                   |   |   |
| WOT RPM, within specifications<br>(in forward gear)               |   |   |

##### - PROPULSION CHECKS

|                                               |  |  |
|-----------------------------------------------|--|--|
| Stern drive unit oil level                    |  |  |
| Power trim oil level (stern drives)           |  |  |
| Drive unit fasteners torque                   |  |  |
| Power trim cylinders fasteners tight          |  |  |
| Propeller nut torque                          |  |  |
| Transmission fluid level                      |  |  |
| Steering operation throughout range           |  |  |
| Power trim operation (stern drives)           |  |  |
| Forward - Neutral - Reverse gear<br>operation |  |  |



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

### 2. MAINTENANCE SCHEDULE

○ : Check/Clean, ◇ : Check ( Replace if necessary), ● : Replace

| Item \ Interval                                 | Which ever comes first |                           |                           |                             |                             |
|-------------------------------------------------|------------------------|---------------------------|---------------------------|-----------------------------|-----------------------------|
|                                                 | Daily                  | Every 250 Hours / 1 years | Every 500 Hours / 2 years | Every 1,000 Hours / 4 years | Every 1,500 Hours / 5 years |
| Coolant level and leakage <sup>1)</sup>         | ○                      |                           |                           |                             |                             |
| Sea water strainer                              | ○                      |                           |                           |                             |                             |
| Exhaust system leakage                          | ○                      |                           |                           |                             |                             |
| Fuel system leakage                             | ○                      |                           |                           |                             |                             |
| Engine oil level and leakage                    | ○                      |                           |                           |                             |                             |
| Battery voltage                                 | ○                      |                           |                           |                             |                             |
| Steering system oil level and leakage           | ○                      |                           |                           |                             |                             |
| Transmission <sup>2</sup> oil level and leakage | ○                      |                           |                           |                             |                             |
| Fuel filter and water separator                 |                        | ●                         |                           |                             |                             |
| Engine oil and oil filter                       |                        | ●                         |                           |                             |                             |
| Sacrificial anode                               |                        | ●                         |                           |                             |                             |
| Connections and corrosion in electric system.   |                        | ◇                         |                           |                             |                             |
| Loose bolts and nuts.                           |                        | ◇                         |                           |                             |                             |
| Loose or damaged hose clamps                    |                        | ◇                         |                           |                             |                             |
| Exhaust bellows                                 |                        | ◇                         | ●                         |                             |                             |
| Sea water pump impeller                         |                        | ◇                         | ●                         |                             |                             |
| Air filter                                      |                        | ◇                         |                           | ●                           |                             |
| Engine Mounts                                   |                        | ◇                         |                           | ●                           |                             |
| Drive belt                                      |                        |                           | ◇                         |                             | ●                           |
| Heat Exchanger (Tube bundle)                    |                        |                           | ◇                         |                             | ◇                           |
| Intercooler (Tube bundle)                       |                        |                           | ◇                         |                             | ◇                           |
| Turbocharger                                    |                        |                           |                           | ◇                           |                             |
| E-VGT Cooler                                    |                        | ◇                         |                           |                             |                             |

1) Replace the coolant every 2 years.

2) For more detailed transmission, follow the transmission manufacturer's manual.

\* NOTE : These procedures are considered normal maintenance.



### CAUTION

YOU SHOULD EXERCISE THE UTMOST CARE TO PREVENT INJURY TO YOURSELF OR ENGINE DAMAGE WHENEVER PERFORMING ANY MAINTENANCE.

### 3. STERNDRIVE & TRANSMISSION MAINTENANCE SCHEDULE

| Maintenance item                                                             | Maintenance intervals | Whichever comes first |              |
|------------------------------------------------------------------------------|-----------------------|-----------------------|--------------|
|                                                                              |                       | Daily                 | 100h / 1year |
| Check sterndrive unit oil level (Transmission)                               |                       | ●                     |              |
| Trim pump oil level                                                          |                       | ●                     |              |
| Steering fluid level                                                         |                       | ●                     |              |
| Check water pickups for debris or marine growth                              |                       | ●                     |              |
| Check water strainer and clean                                               |                       | ●                     |              |
| Inspect sterndrive unit anodes and replace if 50% eroded                     |                       | ●                     |              |
| Lubricate propeller shaft and the retorque nut                               |                       | ●                     |              |
| Touch-up power package paint and spray with Corrosion Guard (Transmission)   |                       |                       | ●            |
| Change sterndrive unit oil (Transmission)                                    |                       |                       | ●            |
| Retorque connection of gimbalring to steering shaft                          |                       |                       | ●            |
| Check steering system and remote control for loose, missing or damaged parts |                       |                       | ●            |
| Lubricate cables and linkages                                                |                       |                       | ●            |
| Inspect U-joints, splines and bellows. Lubricate U-joints splines            |                       |                       | ●            |
| Check engine alignment                                                       |                       |                       | ●            |
| Check gimbal bearing and engine coupler                                      |                       |                       | ●            |
| Check continuity circuit for loose or damaged connections                    |                       |                       | ●            |
| Check MerCathode unit                                                        |                       |                       | ●            |


#### Filter replacement (ZF Transmission)

- 1) The first replacement must be preformed after 25 hours of operation.
- 2) The oil must be changed whenever the filter is replaced.



### CAUTION

**YOU SHOULD EXERCISE THE UTMOST CARE TO PREVENT INJURY TO YOURSELF OR ENGINE DAMAGE WHENEVER PERFORMING ANY MAINTENANCE.**

[illegible]

### CHAPTER 14

### TROUBLESHOOTING GUIDE

#### ■ Starter motor does not crank the engine

| Possible Causes                                             |                                                                                         |
|-------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| • Engine stop switch “ON” position                          | • Engine is not shifted to neutral position<br>• Wrong neutral switch connection to EOI |
| • Weak battery or battery connections are loose or corroded | • Starter motor solenoid or slave solenoid failure                                      |
| • Ignition key switch failure                               | • Blown fuse at EOI                                                                     |
| • Wiring or electrical connection fault                     | • Defective ECU                                                                         |

#### ■ Engine cranks but does not start

| Possible Causes                            |                                         |
|--------------------------------------------|-----------------------------------------|
| • Weak battery or bad starter motor        | • Low fuel pressure                     |
| • No fuel                                  | • Low compression pressure              |
| • ECU not functioning                      | • Crank position sensor not functioning |
| • Incorrect starting procedure             | • Fuel is not reaching the engine       |
| • Faulty fuel filter or electric fuel pump | • Bad fuel quality or water in fuel     |
| • Faulty fuse                              | • Faulty injector                       |

#### ■ Engine starts with difficulty or starts and stalls

| Possible Causes                         |                                               |
|-----------------------------------------|-----------------------------------------------|
| • Low fuel pressure in fuel rail        | • Fuel return line not connected at injector  |
| • Leakage in high pressure fuel circuit | • Faulty alternator or voltage regulator      |
| • Faulty fuse                           | • No engine coolant temperature sensor signal |
| • No rail pressure sensor signal        | • Low battery voltage                         |
| • Oil level too high or too low         | • Low compression pressure                    |
| • ECU program error or hardware fault   | • Clogged fuel filter                         |

#### ■ Engine idle is rough

| Possible Causes                              |                                   |
|----------------------------------------------|-----------------------------------|
| • Fuel return line not connected at injector | • Low compression pressure        |
| • No rail pressure sensor signal             | • Injector clamp poorly tightened |
| • Wiring harness open or poor connection     | • Faulty high pressure fuel pump  |
| • Bad fuel quality or water in fuel          | • Faulty injector                 |
| • Clogged fuel filter / air filter           | • Carbon deposit on the injector  |

### ■ Engine rattling, noisy engine

| Possible Causes                                   |                                               |
|---------------------------------------------------|-----------------------------------------------|
| • Compensation of individual injector not adapted | • No engine coolant temperature sensor signal |
| • Low compression pressure                        | • Clogged injector return line                |
| • No rail pressure sensor signal                  | • Faulty injector                             |
| • Poor injector O-ring                            | • Carbon deposit on the injector              |

### ■ Uncommanded acceleration / deceleration

| Possible Causes                            |                                                  |
|--------------------------------------------|--------------------------------------------------|
| • Intermittent faulty fuel line connection | • Oil suction                                    |
| • No rail pressure sensor signal           | • ECU program error or hardware fault            |
| • Leakage in intake system                 | • Damaged turbocharger or leakage in vacuum line |
| • Clogged fuel filter                      | • Low compression pressure                       |
| • Leakage in high pressure fuel circuit    | • Injector needle stuck                          |

### ■ Engine stops

| Possible Causes                                  |                                                             |
|--------------------------------------------------|-------------------------------------------------------------|
| • Run out of fuel / Safety Stop Switch activated | • Fuel return line not connected at injector                |
| • Fuel feed line not connected                   | • Fuel pressure regulator valve contaminated, stuck, jammed |
| • Leakage in high pressure fuel circuit          | • Rail pressure regulator valve contaminated, stuck, jammed |
| • Fuel out of specification                      | • Faulty alternator or voltage regulator                    |
| • Bad fuel quality or water in fuel              | • Faulty high/low pressure fuel pump                        |
| • Clogged low pressure fuel circuit              | • ECU program error or hardware fault                       |

### ■ Performance loss

| Possible Causes                                   |                                           |
|---------------------------------------------------|-------------------------------------------|
| • Compensation of individual injector not adapted | • Leakage at the injector                 |
| • Clogged air filter                              | • Fuel or intake air temperature too high |
| • Oil level too high or too low                   | • Engine coolant temperature too high     |
| • Damaged turbocharger or intake air leakage      | • Low compression pressure                |
| • Clogged fuel filter                             | • Poor valve clearance                    |

**CHAPTER 15**  
**WARRANTY**

**HYUNDAI SEASALL RATING CATEGORIES FOR MARINE ENGINE**

**S5 : Pleasure Duty**

- Full power operation restricted to within 10% of total use period
  - \* Continuous maximum output restricted to 0.5 hours within 12 hours period
- Cruising speed (RPM) at engine RPM < 90% of rated speed (RPM)
- Operating less than 400 hours per year

**S4 : Special Pleasure Duty / Special Light Duty Commercial**

- Full power operation restricted to within 10% of total use period
  - \* Continuous maximum output restricted to 1 hours within 12 hours period
- Cruising speed (RPM) at engine RPM < 90% of rated speed (RPM)
- Operating less than 1,000 hours per year

**S3 : Light Duty Commercial**

- Full power operation restricted to within 20% of total use period
  - \* Continuous maximum output restricted to 2 hours within 12 hours period
- Cruising speed (RPM) at engine RPM < 90% of rated speed (RPM)
- Operating less than 1,500 hours per year

**S2 : Medium Duty Commercial**

- Full power operation restricted to within 30% of total use period
  - \* Continuous maximum output restricted to 4 hours within 12 hours period
- Cruising speed (RPM) at engine RPM < 90% of rated speed (RPM)
- Operating less than 3,000 hours per year

**S1 : Heavy Duty Commercial**

- Uninterrupted and unlimited use at full power.

**APPLICATION OF WARRANTY COVERAGE**

Warranty coverage is available only to retail customers who purchase from a dealer authorized by Hyundai SeasAll to distribute the product in the country in which the sale occurred, and then only after the Hyundai SeasAll specified pre-delivery inspection process is completed and documented. Warranty coverage becomes available upon proper registration of the product by the authorized dealer. Routine maintenance outlined in the Installation and Operation Manual must be performed in a timely fashion in order to obtain warranty coverage. Hyundai SeasAll reserves the right to make any warranty coverage contingent upon proof of proper maintenance.

This warranty may be rendered invalid at Hyundai SeasAll's discretion based upon:

- 1) Modifications not authorized by Hyundai SeasAll
- 2) Handling errors
- 3) Improperly performed Pre-Delivery Inspection
- 4) Unsuitable fuels, coolant or lubricants
- 5) Using the engine outside of the specified duty cycle rating
- 6) Overloading
- 7) Improperly performed repairs
- 8) Improper maintenance interval(s)
- 9) No submitted Pre-Delivery Inspection Card and Warranty Registration Card



# INSTALLATION & OPERATION MANUAL

## S270 Series Engines

### DURATION OF WARRANTY

#### Leisure Applications

| Engine                  | Rating | Base Engine |       | Extended Major Components<br>(Includes Base Engine Warranty) |       |
|-------------------------|--------|-------------|-------|--------------------------------------------------------------|-------|
|                         |        | years       | hours | years                                                        | hours |
| S270/D170/R200<br>/U125 | S5     | 2           | 1,000 | 4                                                            | 2,000 |
| **H380/L500             | S5     | 2           | -     | 4                                                            | 5,000 |

\*\* Operating less than 1,500 hours per year and Full Power operation < 10% of total use period

- Warranty period is limited by Years or Hours whichever occurs first.
- Major Components : Engine Block Casting, Crankshaft Forging, Connecting Rods, Camshaft Forging, Transmission Cover/Housing, Flywheel Housing, Intake Manifold, Fresh Water Pump Housing and Oil Pan.
- Cylinder Liner or Cylinder Bore scratches are not included in extended major part warranty coverage.

#### Commercial Applications

| Engine                  | Rating | Base Engine |       | Extended Major Components<br>(Includes Base Engine Warranty) |        |
|-------------------------|--------|-------------|-------|--------------------------------------------------------------|--------|
|                         |        | years       | hours | years                                                        | hours  |
| S270/D170/R200<br>/U125 | S4     | 1           | 1,000 | 3                                                            | 2,000  |
| S220/D150               | S3     | 1           | 1,500 | 3                                                            | 6,500  |
| H380/L500               | S1     | 1           | 5,000 | 3                                                            | 10,000 |
| M70/M100/M140           |        |             |       |                                                              |        |
| Q280/Q330/Q385<br>/Q405 |        |             |       |                                                              |        |

- Warranty period is limited by Years or Hours whichever occurs first.
- Major Components : Engine Block Casting, Crankshaft Forging, Connecting Rods, Camshaft Forging, Transmission Cover/Housing, Flywheel Housing, Intake Manifold, Fresh Water Pump Housing and Oil Pan.
- Cylinder Liner or Cylinder Bore scratches are not included in extended major part warranty coverage.

Hyundai SeasAll Rating Categories For Marine Auxiliary Engines  
(Ratings in accordance with ISO 8528 )

#### Standby Power

- 1) Operating less than 500 hours per year with average 90% load of the declared Standby Power
- 2) No overload capability is available for this rating.

#### Prime Power

- 1) Average power operation does not exceed 70% of the declared Prime Power.
- 2) A 10% overload is permissible for 1 hour per 12 hours of operation.
- 3) Maximum prime power shall not exceed 500 hours per year.

### Marin Auxiliary Engine

| Engine      | Rating        | Base Engine |       | Extended Major Components<br>(Included Base Engine Warranty) |        |
|-------------|---------------|-------------|-------|--------------------------------------------------------------|--------|
|             |               | years       | hours | years                                                        | hours  |
| L500G       | Standby Power | 2           | 1,000 | 4                                                            | 3,000  |
| H350G/L460G | Prime Power   | 1           | -     | 3                                                            | 10,000 |

### Genset

| Model                           |                                | Warranty Classification |                        |
|---------------------------------|--------------------------------|-------------------------|------------------------|
|                                 |                                | Prime Power             | Standby Power          |
| 50 HZ<br>1,500 RPM<br>220V * 3P | M35GS/ M43GS / M56GS           | 1year                   | 2 years/<br>1000 hours |
|                                 | Q150GS/ Q176GS/ Q210GS/ Q230GS |                         |                        |
| 60 HZ<br>1,800 RPM<br>220V * 3P | M40GS/ M55GS/ M70GS            |                         |                        |
|                                 | Q165GS/ Q200GS/ Q230GS/ Q270GS |                         |                        |

### WARRANTY STARTING DATE

Warranty Begins:

- 1) When engine is delivered to the first retail purchaser
- 2) When the engine is first leased or rented
- 3) When the product reaches the first day of the 7th month after the product has been shipped from Hyundai SeasAll, the warranty date will be started automatically. If you submit the "Pre-Delivery Inspection Card" and "Warranty Registration Card", the starting date can be changed to the date on your documents.

### WARRANTY REGISTRATION

Warranty Registration Card must be submitted to Hyundai SeasAll within 30 days of the Warranty Starting Date. The Warranty Registration Card identifies information on customer and product, models and serial numbers, date of sale, type of use and the selling dealer etc. *If the 'Warranty Registration Card' and 'Pre-Delivery Inspection Card' are not approved or not submitted to Hyundai SeasAll within 30 days from Warranty Starting Date , Hyundai SeasAll reserves the right to decline warranty reimbursement.*

### TRANSFER OF WARRANTY COVERAGE BETWEEN OWNERS

This limited warranty is transferable to a subsequent purchaser, but only for the remainder of the unused portion of the limited warranty. To transfer the warranty to the subsequent owner, the revised "Warranty Registration Card" and "Pre-Delivery Inspection Card" should be submitted to Hyundai SeasAll's distributor or dealer. Upon processing the transfer of warranty, Hyundai SeasAll will verify the warranty registration of the new owner.

## **WHAT HYUNDAI SEASALL WILL DO**

Hyundai SeasAll will pay for all parts and labor needed to repair the damage to the product resulting from a defect in materials or factory workmanship.

The warranty does not apply to any damage or defect that is the result of abnormal use or carelessness.

The repair or replacement of parts, or the performance of service under this warranty does not extend the life of this warranty beyond its original expiration date.

## **OWNER'S OBLIGATIONS**

It is the owner's obligation to install, operate, maintain and care for Hyundai SeasAll engines in accordance with the instructions and requirements stated in the Installation and Operation Manual.

The owner is responsible for providing enough time and cooperation to get the engine repaired by an authorized dealer, and to deliver it to a proper facility for repair.

The owner is responsible for the cost for warranty inspection, including hauling out, launching and transportation.

## **BUSINESS PARTNER'S OBLIGATIONS**

It is Hyundai SeasAll's Distributor and/or Dealer's responsibility to support the retail customer with prompt diagnosis and repair whether or not the engine was sold by the servicing dealer or by the Distributor responsible for the territory.

It is Hyundai SeasAll's Distributor's responsibility to communicate all warranty issues to the factory in a timely manner so that they can be quickly resolved.

## **HOW TO OBTAIN WARRANTY COVERAGE**

The customer must provide Hyundai SeasAll with a reasonable opportunity to repair the engine, as well as reasonable access to the product for warranty service. Warranty claims shall be made to a Hyundai SeasAll Authorized Repair Facility to service the product. Purchaser shall not, unless requested by Hyundai SeasAll, ship the product or parts of the product directly to Hyundai SeasAll. The warranty registration card is the only valid registration identification and must be presented to the dealer at the time warranty service is requested in order to obtain coverage.

### **WHAT IS COVERED**

Hyundai SeasAll warrants its products to be free of defects in material and workmanship during the warranty period.

### **LIMITATIONS – EXPENDABLE PARTS**

Not included are the following expendable parts:

- Filters : fuel filter, engine oil filter, air filter
- Lubricants : engine oil, coolant, power steering oil.
- Rubber products : seawater pump impeller, rubber hoses, belts, engine coupler, rubber isolation mounts, bellows.
- Gaskets, anodes.

### **WHAT IS NOT COVERED**

- Fuel injector or filter cleaning
- Belt, cable adjustments or lubrication checks made in connection with normal services.
- Damage caused by neglect, lack of maintenance, accidents, abnormal operation, improper installation or service, unapproved modifications or freezing temperatures.
- Haul-out (crane), launching or towing charges, removal and/or replacement of boat partitions or material for necessary access to the product, all related transportation charges and/or travel time, etc.
- All incidental and/or consequential damages (storage charges, telephone or rental charges of any type, inconvenience or loss of time or income) are the owner's responsibility.
- Use of other than Hyundai SeasAll genuine replacement parts when making warranty repairs.
- Participating in or preparing for racing or other competitive activity.
- Water entering the engine via the air inlet filter or exhaust system or submersion. Water in the starter motor.
- Failure of any parts caused by lack of cooling water.
- Damage caused by blockage of the cooling system by foreign matter.
- Use of fuels and lubricants that are not suitable for use with or on the product as specified in the Installation and Operation Manual.
- Normal wear and tear
- Storage damage ( such as paint scratches )
- Cost resulting from ineffective or repeated repairs; improper repairs due to misdiagnosis.
- Owner's personal cost ( indirect loss ) resulting from maintenance.

### **TRANSMISSION AND STERNDRIVE WARRANTIES**

Transmissions and drive systems (ZF, Mercury Marine etc.) are covered under separate warranties, provided and serviced by those companies. For information on those warranties, please see the separate booklets included in the original packaging of your Hyundai SeasAll purchase.

This card is essential for registration of the customer's warranty.  
Please fill out the following registration card in English.

Date of sale

| Month | Day | Year |
|-------|-----|------|
|       |     |      |

If Warranty Transfer , Check box ☐**OWNER'S INFORMATION**

|                    |  |                         |  |
|--------------------|--|-------------------------|--|
| Name or Company    |  | E-Mail Address          |  |
| Country            |  | State / Province / City |  |
| Operating Location |  |                         |  |

**DEALER INFORMATION**

|                    |  |                  |  |
|--------------------|--|------------------|--|
| Dealer / Installer |  | Distributor Name |  |
| City               |  | E-Mail Address   |  |

**ENGINE INFORMATION**

|                   |                                 |                               |
|-------------------|---------------------------------|-------------------------------|
| Number of Engines | Single <input type="checkbox"/> | Dual <input type="checkbox"/> |
|-------------------|---------------------------------|-------------------------------|

|                   |  |                       |  |
|-------------------|--|-----------------------|--|
| Engine Model      |  | Gear Model            |  |
| Engine Serial No. |  | Gear/Drive Serial No. |  |
|                   |  | Transom Serial No.    |  |

|                   |  |                       |  |
|-------------------|--|-----------------------|--|
| Engine Model      |  | Gear Model            |  |
| Engine Serial No. |  | Gear/Drive Serial No. |  |
|                   |  | Transom Serial No.    |  |

**BOAT INFORMATION**REPOWER ☐

|              |                                   |                                     |                                   |                                     |                                       |                                |
|--------------|-----------------------------------|-------------------------------------|-----------------------------------|-------------------------------------|---------------------------------------|--------------------------------|
| Manufacturer |                                   | Material                            | Steel <input type="checkbox"/>    | Alu. <input type="checkbox"/>       | FRP <input type="checkbox"/>          | Wood. <input type="checkbox"/> |
| Model        |                                   | LOA                                 | ft                                | Beam                                | ft                                    |                                |
| Boat Type    |                                   | Hull ID                             |                                   |                                     |                                       |                                |
| Type of Use  | Pleasure <input type="checkbox"/> | Commercial <input type="checkbox"/> | Planning <input type="checkbox"/> | Semi Disp. <input type="checkbox"/> | Displacement <input type="checkbox"/> |                                |

Dealer's Instructions: Dealers must complete this card to register the warranty. Please return the copy to your national Importer/Distributor immediately. Unregistered engines are subject to warranty rejection.

**REMARKS**

SIGNATURE : \_\_\_\_\_

NEW THINKING. NEW POSSIBILITIES.



**HYUNDAI SEASALL**